


Service Manual

PIONEER®
The Art of Entertainment



ORDER NO.
ARP2467

STEREO DOUBLE CASSETTE DECK RECEIVER

RX-Z35

RX-Z45

RX - Z35 AND RX - Z45 HAVE THE FOLLOWING :

Type	Model		Power Requirement	Remarks
	RX - Z35	RX - Z45		
SDXJ	○	—	AC110V, 120V - 127V, 220V, 240V (Switchable)	
YPWXJ	○	—	AC240V only	
HEXJ	—	○	AC220V - 230V, 240V (Switchable)*	

* Change the connection of the power transformer's primary wiring

- This manual is applicable to the following : RX - Z35/SDXJ and YPWXJ ; RX - Z45/HEXJ.
- For the following : RX - Z35/YPWXJ ; RX - Z45/HEXJ, refer to page 74 - 107.
- Ce manuel pour le service comprend les explications de réglage en français.
- Este manual de servicio trata del método ajuste escrito en español.

CONTENTS

1. EXPLODED VIEWS, PACKING AND PARTS LIST	2	4. AJUSTE	65
2. SCHEMATIC AND PCB CONNECTIONS		5. IC INFORMATION	71
DIAGRAMS	12	6. FOR RX - Z35/YPWXJ AND RX - Z45/HEXJ	
3. PCB PARTS LIST	47	TYPES	74
4. ADJUSTMENTS	53	7. PANEL FACILITIES	108
4. REGLAGE	59	8. SPECIFICATIONS	113


PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
 © **PIONEER ELECTRONIC CORPORATION 1992**

DFV MAR. 1992 Printed in Japan

1. EXPLODED VIEWS, PACKING AND PARTS LIST

- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Parts marked by "⦿" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

1.1 PACKING



Parts list of Packing

Mark	No.	Description	Parts No.
NSP	1	FM ANTENNA	ADH1008
	2	DRY CELL BATTERY (R03, AAA)	AEX -021
	3	FRONT PAD	AHA1474
	4	REAR PAD A	AHA1475
	5	PACKING CASE	AHD2209
NSP	6	SHEET	AHG1086
NSP	7	BAG	AHG1105
	8	OPE. INSTRUCTIONS (English)	ARB1350
	9	OPE. INSTRUCTIONS (Spanish)	ARC1322
	10	REMOTE CONTROL UNIT (CU - RX011)	AXD1257
	11	BATTERY COVER	AZA1361
	12	LOOP ANTENNA	ATB1006

1.2 EXTERIOR

Parts list of Exterior

Mark	No.	Description	Parts No.
	1	VOLUME KNOB	AAB1264
	2	MIXING KNOB (MIC LEVEL)	AAB1265
	3	TUNER PANEL	AAK2238
	4	AMP. PANEL	AAK2239
	5	INDICATOR PANEL	AAK2240
	6	DOOR PANEL	AAK2241
	7	REMOTE FILTER	AAK2245
	8	CASSETTE DOOR (L)	AAN1302
	9	CASSETTE DOOR (R)	AAN1303
	10	LABEL (PAPER)	AAX1301
NSP	11	VOLUME ASSEMBLY	AWZ3829
●	12	TUNER ASSEMBLY	AWZ3835
	13	SCREW (STEEL)	ABA1095
	14	SPRING	ABH1078
	15	KEEP PLATE	ABK1017
△	16	AC POWER CORD	ADG1051
NSP	17	NYLON BINDER	AEC-093
NSP	18	BINDER	AEC-826
	19	LEG ASS'Y	AEC-847
	20	STRAIN RELIEF	AEC-882
NSP	21	PCB SPACER	AEC1100
NSP	22	NYLON BINDER	AEC1384
NSP	23	CHASSIS	ANA1162
	24	REAR PANEL	ANC1837
	25	BONNET CASE	ANE1346
NSP	26	JACK HOLDER	ANG1613
NSP	27	ASSEMBLY HOLDER	ANG1614
NSP	28	RADIATOR HOLDER	ANG1615
NSP	29	RADIATOR	ANH1357
●	30	DOLBY ASSEMBLY	AWZ3967
●	31	POWER ASSEMBLY	AWZ3832
	32	SCREW	BBZ30P080FZK
	33	SCREW	BPZ26P080FMC
	34	NUT	NK90FUC
	35	SCREW	BBZ30P060FMC


Mark	No.	Description	Parts No.
	36	SCREW	BBZ30P060FZK
	37	SCREW	VPZ30P080FMC
	38	SCREW	BPZ30P100FZK
△	39	FUSE (T800mA/250V, FU601)	AEK-507
△	40	FUSE (T800mA/250V, FU602)	AEK-507
△	41	FUSE (T500mA/250V, FU603)	AEK-505
△	42	FUSE (T800mA/250V, FU604)	AEK-507
△	43	VOLTAGE SELECTOR (S1)	AKX-507
△	44	POWER TRANSFORMER (T1)	ATS1389
NSP	45	TRANSE ASSEMBLY	AWZ3863
	46	SCREW	ABA1153

A

B

C


D



FRONT PANEL SECTION
(Refer to pages 6 and 7.)


Parts No.

- BBZ30P060FZK
VPZ30P080FMC
BPZ30P100FZK
1) AEK-507
2) AEK-507
3) AEK-505
4) AEK-507
AKX-507
T1) ATS1389
AWZ3863
ABA1153



FRONT PANEL SECTION
(Refer to pages 6 and 7.)

1.3 FRONT PANEL SECTION



Parts list of Front panel section

Mark	No.	Description	Parts No.
A	1	POWER BUTTON (STANDBY/ON)	AAD2123
	2	SURROUND BUTTON (SURROUND & STEREO WIDE)	AAD2124
	3	P. BASS BUTTON (SUPER BASS, VOCAL CANCEL)	AAD2125
	4	TUNING BUTTON	AAD2126
	5	FUNCTION BUTTON	AAD2127
	6	COPY BUTTON (HIGH-SPEED COPY)	AAD2128
	7	DOLBY KNOB (DOLBY NR)	AAE1142
	8	DECK KNOB A (■)	AAE1143
	9	DECK KNOB B (■ / ▲)	AAE1144
	10	DECK KNOB C (►►)	AAE1145
B	11	DECK KNOB D (◀◀)	AAE1151
	12	DECK KNOB E (▶▶)	AAE1152
	13	DECK KNOB F (●)	AAE1153
	14	FUNCTION LENS	AAK2242
	15	P. BASS LENS	AAK2243
	16	SURROUND LENS	AAK2244
	17	SCREW (STEEL)	ABA1095
	18	SWITCH ASSEMBLY	AWZ3836
	19	FRONT PANEL	AMB1947
	20	DISPLAY ASSEMBLY	AWZ3837
C	21	DECK KNOB HOLDER	ANG1616
	22	HEADPHONE ASSEMBLY	AWZ3834
	23	CASSETTE MECHA UNIT	AWY1174
	24	DAMPER ASSY	AXA1008
	25	SCREW	BPZ26P080FMC
	26	SCREW	VPZ30P080FMC
D			

1.4 CASS

Parts list

Mark	No.
	1
	2
	3
	4
	5
	6
	7
	8
	9
	10
	11
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23
	24
	25
	26
	27
	28
	29
	30
	31
	32
	33
	34
	35
	36
	37
	38
	39
	40
	41
	42
	43
	44
	45
	46
	47
	48
	49
	50
	51
	52
	53
	54
	55
	56

Parts list of Front panel section

Mark	No.	Description	Parts No.
A	1	POWER BUTTON (STANDBY/ON)	AAD2123
	2	SURROUND BUTTON (SURROUND & STEREO WIDE)	AAD2124
	3	P. BASS BUTTON (SUPER BASS, VOCAL CANCEL)	AAD2125
	4	TUNING BUTTON	AAD2126
	5	FUNCTION BUTTON	AAD2127
	6	COPY BUTTON (HIGH-SPEED COPY)	AAD2128
	7	DOLBY KNOB (DOLBY NR)	AAE1142
	8	DECK KNOB A (II)	AAE1143
	9	DECK KNOB B (■ / ▲)	AAE1144
	10	DECK KNOB C (► ►)	AAE1145
B	11	DECK KNOB D (◀ ◀)	AAE1151
	12	DECK KNOB E (►)	AAE1152
	13	DECK KNOB F (●)	AAE1153
	14	FUNCTION LENS	AAK2242
	15	P. BASS LENS	AAK2243
	16	SURROUND LENS	AAK2244
	17	SCREW (STEEL)	ABA1095
	18	SWITCH ASSEMBLY	AWZ3836
	19	FRONT PANEL	AMB1947
	20	DISPLAY ASSEMBLY	AWZ3837
NSP	21	DECK KNOB HOLDER	ANG1616
NSP	22	HEADPHONE ASSEMBLY	AWZ3834
	23	CASSETTE MECHA UNIT	AWY1174
	24	DAMPER ASSY	AXA1008
	25	SCREW	BPZ26P080FMC
	26	SCREW	VPZ30P080FMC

1.4 CASSETTE MECHA UNIT

Parts list

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
	1	SPRING	AZB1336		57	BUTTON R HOLDER	AZN2163
	2	SPRING	AZB1337		58	BUTTON L HOLDER	AZN2164
	3	SPRING	AZB1338		59	P HOLDER	AZN2165
	4	SPRING	AZB1339		60	CONNECT PLATE	AZN2166
	5	SPRING	AZB1340				
	6	CASSETTE SPRING	AZB1343		61	CONNECT ARM	AZN2167
	7	SPRING	AZB1344		62	RELEASE ARM	AZN2168
	8	SPRING	AZB1346		63	MOTOR HOLDER	AZN2169
	9	SPRING	AZB1347		64	BASE SPI ASSY	AZN2171
	10	SPRING	AZB1348		65	TAPE GUIDE	AZN2174
	11	PLATE SPRING	AZB1349		66	E HEAD	AZP1025
	12	WASHER	AZB1350		67	R/P HEAD	AZP1036
	13	WASHER	AZB1351		68	MOTOR ASSY	AZX1037
	14	SPRING	AZB1352		69	SWITCH (S2)	ASX1014
	15	SPRING	AZB1353		70	CASSETTE MECHA	AWY1150
	16	EARTH LUG	AZB1354		71	2P WIRE ASSY A (J4)	ADD1104
	17	SCREW	AZB1355		72	2P WIRE ASSY B (J5)	ADD1105
	18	SCREW	AZB1356		73	2P WIRE ASSY C (J7)	ADD1106
	19	SCREW	AZB1357		74	4P JUMPER WIRE (J8)	ADD1107
	20	SCREW	AZB1358		75	2P WIRE ASSY D (J3)	ADD1108
	21	SCREW	AZB1359		76	2P WIRE ASSY E (J6)	ADD1109
	22	SCREW	AZB1360		77	3P HEAD WIRE ASSY (J1)	ADX1613
	23	SCREW	AZB1361		78	5P HEAD WIRE ASSY (J2)	ADX1614
	24	SCREW	AZB1362		79	SWITCH (S1)	ASX1014
	25	SCREW	AZB1363		80	SWITCH (S3)	ASX1014
	26	SCREW	AZB1364		81	CERAMIC CAPACITOR (C1)	CKDYF223Z50
	27	PC BOARD	AZN2111		82	SWITCH (S4)	ASX1014
	28	FRAM ASSY	AZN2113		83	SWITCH (S5)	ASX1014
	29	FUNCTION PLATE	AZN2116				
	30	REC STOPPER	AZN2117	NSP	101	SPRING	AZB1341
				NSP	102	SPRING	AZB1342
	31	SW LEVER	AZN2118	NSP	103	SPRING	AZB1345
	32	REC LEVER	AZN2119	NSP	104	CHASSIS	AZN2112
	33	PLAY LEVER	AZN2120	NSP	105	FRAM	AZN2114
	34	REW LEVER	AZN2121				
	35	FF LEVER	AZN2122	NSP	106	METAL	AZN2115
				NSP	107	SPINDLE BASE	AZN2130
	36	SE LEVER	AZN2123	NSP	108	T REEL ASSY	AZN2131
	37	PAUSE LEVER	AZN2124	NSP	109	REEL CAP	AZN2132
	38	PAUSE ARM	AZN2125	NSP	110	REEL GEAR	AZN2133
	39	BELT	AZN2126				
	40	BELT	AZN2127	NSP	111	FELT	AZN2134
				NSP	112	T REEL	AZN2135
	41	P IDLER ARM	AZN2128	NSP	113	S REEL	AZN2136
	42	PL IDLER	AZN2129	NSP	114	FF IDLER	AZN2137
	43	INTER LOCK	AZN2138	NSP	115	IDLER BASE	AZN2141
	44	EJECT LEVER	AZN2139				
	45	PF FF IDLER ASSY	AZN2140	NSP	116	PF IDLER	AZN2142
				NSP	117	PF PULLY HOLDER	AZN2143
	46	SENSER	AZN2148	NSP	118	PF PULLY	AZN2144
	47	AS BASE	AZN2149	NSP	119	PF BUSH	AZN2145
	48	CAM GEAR	AZN2150	NSP	120	SHAFT	AZN2146
	49	SENSER LEVER	AZN2151				
	50	CONTROL LEVER	AZN2152	NSP	121	FELT	AZN2147
				NSP	122	FLY WHEEL	AZN2154
	51	FW ASSY	AZN2153	NSP	123	RING	AZN2155
	52	PINCH ARM	AZN2157	NSP	124	CAPSTAN SHAFT	AZN2156
	53	PINCH ROLLER	AZN2158	NSP	125	MOTOR PULLEY	AZN2170
	54	HEAD BASE	AZN2159				
	55	HEAD HOLDER	AZN2160	NSP	126	MOTOR	AZX1038
	56	SWITCH PLATE	AZN2162	NSP	127	NYLON BINDER	AEC-093
				NSP	128	JUMPER CONNECTOR (7PL)	KPD7L

1

2

3

4

5


6


A

B

C

D





A
B
C
D

2. SCHEMATIC AND PCB CONNECTIONS DIAGRAMS


2.1 OVERALL SCHEMATIC DIAGRAM


A

B

C

D





1. RESISTORS:

Indicated in Ω , $\frac{1}{4}W$, $\frac{1}{8}W$, $\pm 5\%$ tolerance unless otherwise noted k : k Ω , M : M Ω , (F) : $\pm 1\%$, (G) : $\pm 2\%$, (K) : $\pm 10\%$ (M) : $\pm 20\%$ tolerance

2. CAPACITORS:

Indicated in capacity (μF)/voltage (V) unless otherwise noted p : pF Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE, CURRENT:

$\square V$: Signal voltage at rated output.
 $\square$: DC voltage (V) at no input signal
Value in () is DC voltage at rated power.
 $\leftarrow$ mA : DC current at no input signal
mV : Signal voltage at FM 1kHz ± 75 kHz DEV.

4. OTHERS:

$\rightarrow$: Signal route.
 $\odot$: Adjusting point.
The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
* marked capacitors and resistors have parts numbers.
 ∇ (RED) : Measurement point
This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

5. SWITCHES (The underline indicates the switch position)

S1 VOLTAGE SELECTOR
AC110V/120-127V/220V/240V

POWER assembly

S201 CHANNEL STEP (9k/10k)

SWITCH assembly

S2061 HIGH-SPEED COPY
S2062 DOLBY NR ON/OFF

DISPLAY assembly

S51 TAPE
S53 ST. CALL
S54 SURROUND & STEREO WIDE
S55 TUNING (UP)
S56 POWER/STANDBY
S57 MEMORY
S58 TUNER
S59 PHONO
S60 TUNING (DOWN)
S61 CD
S62 BAND
S64 FM MONO
S65 VOCAL CANCEL
S2063 SUPER BASS

A

B



This P. C. B connection diagram is viewed from the parts mounted side.

A

A

B


B

C

C

D

D



To POWER assembly CN109 (P26)

NOTE





1. This P.C.B connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.


P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarized)
		Capacitor (Non-polarized)

Others


P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with ⊙ (double circles) shows negative terminal.
4. The diode terminal marked with ⊙ (double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.






11




Q616 IC602 Q621 Q622 Q607 IC601 Q512 Q508 IC502 Q510 Q505 Q501 Q503 Q511 Q507 Q509
Q606 Q614 Q605 Q601 Q405 Q406 Q612 Q602 Q608 Q506 Q616 Q502 Q613 Q504 Q610 Q609 Q611
Q403 Q2407-2409 Q407 Q408 Q401 Q402 IC404 Q2404 IC402 Q2403 IC501
IC401 Q2402 Q2410 Q411 Q412 Q2401 IC306 IC304 Q305-307 IC303 IC302 IC301
VR301 VR2301 VR401 VR402 VR2401-2404


HEADPHONE assembly





CASSETTE MECHA UNIT (1/3)(AWY1174)



CASSETTE MECHA UNIT (2/3)(AWY1174)



CASSETTE MECHA UNIT (3/3)(AWY1174)





POWER assembly (AWZ3832 :SDXJ)(AWZ415:

IC601 Q512 Q508 IC502 Q510
Q6 Q612 Q602 Q608 Q506 Q616 Q502 Q613 Q504
Q409 Q407 Q408 Q401 Q402 IC404 Q2404 IC402 Q2403
IC304 Q305-307 IC303 IC302 IC301

This P. C. B connection diagram is viewed from the parts mounted side.

RX - Z35



- (A) To DOLBY assembly CN110 (➡ P44)
- (B) To DISPLAY assembly J107 (➡ P35)
- (C) To DOLBY assembly CN2104 (➡ P43)
- (D) To DISPLAY assembly J111 (➡ P35)
- (E) To TUNER assembly CN109 (➡ P18)
- (F) To DISPLAY assembly J108 (➡ P34)



NOTE
1. This P.C.B connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
Q504		Transistor
Q215		Radiator type transistor
D203		Diode
R237		Resistor
C513		Capacitor (Polarized)
C518		Capacitor (Non-polarized)


P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with ⊕ (double circles) shows negative terminal.
4. The diode terminal marked with ⊕ (double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.


This P. C. B. connection diagram is viewed from the foil side.




To DISPLAY assembly 1108 (▶ P34)
To TUNER assembly CN109 (▶ P18)
To DISPLAY assembly 1111 (▶ P35)
To DOLBY assembly CN2104 (▶ P43)
To DISPLAY assembly 1107 (▶ P35)
To DOLBY assembly CN110 (▶ P44)




2.4 DISPLAY ASSEMBLY, SWITCH ASSEMBLY AND VOLUME ASSEMBLY



This P. C. B. connection diagram




This P. C. B. connection diagram is viewed from the foil side.



34

assembly CN107 (➡ P25)

[illegible]

1. This P.C.B connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

Others

3. The capacitor terminal marked with $\odot$ (double circles) shows negative terminal.
4. The diode terminal marked with $\odot$ (double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.

A

B

C

D

E

F


To POWER assembly CN111
(P23)


To POWER assembly CN107
(P23)

To POWER assembly CN108
(P23)

- POWER IN R
 - POWER IN GND
 - POWER IN L
 - DOLBY ON/OFF
 - HIGH SPEED
 - LM7001 CE
 - PB MUTE
 - REC
 - STEREO
 - TUNED
 - LM7001 DATA
 - LM7001 CLK
 - PLAY2
 - PLAY1
 - 9k/10k
- DOLBY P/R
 - DECK 4066 CTRL
 - 4052 INH
 - 4052 A
 - 4052 B
 - STAND-BY
 - AUDITION
 - BIAS OSC
 - MUTE RY
 - REC MUTE
- DIG CND
 - AC
 - 18V
 - MOTOR +12V
 - REMOTE OUT
 - SIC +12V
 - SIC -12V
 - SIC +5V
 - FUNCTION OUT L
 - FUNCTION OUT GND
 - FUNCTION OUT R

DISPLAY assembly (AWZ3837)





A

B

C

D

E


F

To POWER assembly J110 (▲ P22)


- AUDITION ON/OFF
- AUDITION L OUT
- AUDITION L IN
- AUDITION GND
- AUDITION R IN
- AUDITION R OUT
- SIG +5V
- SIG -12V
- ECHO D. GND
- ECHO OUT
- ECHO A. GND
- ECHO IN

To POWER assembly J2104 (▲ P23)


- PB MUTE
- PB OUT R
- PB IN R
- PB GND
- PB IN L
- PB OUT L
- DOLBY ON/OFF
- DOLBY R/P
- REC OUT R
- REC IN R
- REC GND
- REC IN L
- REC OUT L
- TAPE1/TAPE2
- SIG +12V





DOLBY assembly (AWZ3967)



IC1401 M50197P



IC1301 CXA1100P



Q1309	Q1310		
VR1301	VR1302	VR1303	VR1304

[illegible]

3. PCB PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ 56 $\times$ 10¹ $\rightarrow$ 561 RD1/8PM Δ Δ Δ J

47k Ω $\rightarrow$ 47 $\times$ 10³ $\rightarrow$ 473 RD1/4PS Δ Δ Δ J

0.5 Ω $\rightarrow$ 0R5 RN2H Δ Δ Δ K

1 Ω $\rightarrow$ 010 RS1P Δ Δ Δ K

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω $\rightarrow$ 562 $\times$ 10¹ $\rightarrow$ 5621 RN1/4PC Δ Δ Δ Δ F

Mark	No.	Description	Parts No.
------	-----	-------------	-----------

LIST OF ASSEMBLIES

NSP	VOLUME ASSEMBLY	AWZ3829
●	TUNER ASSEMBLY	AWZ3835
NSP	SWITCH ASSEMBLY	AWZ3836
●	DISPLAY ASSEMBLY	AWZ3837
●	DOLBY ASSEMBLY	AWZ3967
●	POWER ASSEMBLY	AWZ3832
NSP	HEADPHONE ASSEMBLY	AWZ3834
NSP	TRANSE ASSEMBLY	AWZ3863

VOLUME ASSEMBLY

SEMICONDUCTORS

IC701	OP-AMP IC	RC4558DXP
IC702	MECHANISM DRIVER IC	TA7291S

Q701	TRANSISTOR	2SC1740S
Q702	TRANSISTOR	2SC1740S

D701	DIODE	1SS252
------	-------	--------

CAPACITORS

C701-704	ELECTR. CAPACITOR	CEAS4R7M50
C705, 706	CERAMIC CAPACITOR	CKCYF103Z50
C707	CERAMIC CAPACITOR	CKCYF473Z50

RESISTORS

VR701	VARIABLE RESISTOR (100k-4B $\times$ 2)	ACX1053
	Other resistors	RD1/8PM Δ Δ Δ J

Mark	No.	Description	Parts No.
------	-----	-------------	-----------

TUNER ASSEMBLY

SEMICONDUCTORS

IC201	AM/FM IC	LA1265S
IC202	PLL IC	LM7001
IC203	MPX IC	AN7470P

Q201	MOS-FET	2SK241
Q202	TRANSISTOR	2SC2786
Q203	TRANSISTOR	2SC2668
Q204	N-FET	2SK161
Q205	TRANSISTOR	2SC2668

Q206, 207	TRANSISTOR	XDA143ES
Q208	TRANSISTOR	2SC1740SLN
Q209	N-FET	2SK246
Q210	TRANSISTOR	2SC1740S

D201, 202	VARI-CAP DIODE	ITT310
D203-207	DIODE	1SS252

COILS & TRANSFORMER

F201	CERAMIC FILTER	ATF-155
F202, 203	CERAMIC FILTER	ATF-107
F204	CERAMIC FILTER	ATF-208

L201	COIL	ATC1003
L202	COIL	ATE-079
L203, 204	AXIAL INDUCTOR	LAU2R2M

T201	COIL	ATC-194
T202	IF TRANSFORMER	ATE-063

CAPACITORS

C203	CERAMIC CAPACITOR	CCMCH040C50
C204	CERAMIC CAPACITOR	CKPUYY103N16
C205	CERAMIC CAPACITOR	CCDRH150J50
C206	ELECTR. CAPACITOR	CEAS330M35
C207	CERAMIC CAPACITOR	CCDCH020C50

Mark No.	Description	Parts No.
C208	CERAMIC CAPACITOR	CKPUYY103N16
C209	CERAMIC CAPACITOR	CKPUYB101K50
C210	CERAMIC CAPACITOR	CCDCH010C50
C211	CERAMIC CAPACITOR	CKPUYY103N16
C212	CERAMIC CAPACITOR	CCMCH330J50
C213	CERAMIC CAPACITOR	CCMCH150J50
C214	CERAMIC CAPACITOR	CCMCH080D50
C215	CERAMIC CAPACITOR	CKPUYB102K50
C216	CERAMIC CAPACITOR	CCDTH150J50
C217	CERAMIC CAPACITOR	CCMCH150J50
C218-220	CERAMIC CAPACITOR	CKPUYY103N16
C221	AXIAL CERAMIC C.	CKPUYF223Z25
C222	AUDIO FILM CAPACITOR	CFTXA104J50
C223, 224	AXIAL CERAMIC C.	CKPUYF223Z25
C225	ELECTR. CAPACITOR	CEAS330M35
C226	AXIAL CERAMIC C.	CCPUSL470J50
C227	CERAMIC CAPACITOR	CKPUYB101K50
C228-230	AXIAL CERAMIC C.	CKPUYF223Z25
C231	ELECTR. CAPACITOR	CEAS330M35
C232	ELECTR. CAPACITOR	CEAS010M50
C233	CERAMIC CAPACITOR	CCDSL271J50
C234	ELECTR. CAPACITOR	CEAS4R7M50
C235	CERAMIC CAPACITOR	CKPUYY103N16
C236	ELECTR. CAPACITOR	CEAS470M16
C237	ELECTR. CAPACITOR	CEAS2R2M50
C238	CERAMIC CAPACITOR	CKCYB222K50
C239	CERAMIC CAPACITOR	CKDYF473Z50
C240	AUDIO FILM CAPACITOR	CFTXA104J50
C241	CERAMIC CAPACITOR	CKPUYY103N16
C242	ELECTR. CAPACITOR	CEAS1R5M50
C243	ELECTR. CAPACITOR	CEAS101M16
C244, 245	CERAMIC CAPACITOR	CCMCH150J50
C246	CERAMIC CAPACITOR	CKPUYB101K50
C247	CERAMIC CAPACITOR	CKPUYY103N16
C248	ELECTR. CAPACITOR	CEANP2R2M50
C249	CERAMIC CAPACITOR	CKCYF473Z50
C250	CAPACITOR (470p)	ACE1039
C251	ELECTR. CAPACITOR	CEAS3R3M50
C252	ELECTR. CAPACITOR	CEAS1R5M50
C253	ELECTR. CAPACITOR	CEASR22M50
C254	AXIAL CERAMIC C.	CKPUYF223Z25
C255	ELECTR. CAPACITOR	CEAS0R1M50
C256	ELECTR. CAPACITOR	CEAS330M35
C257, 258	CERAMIC CAPACITOR	CKMYB152K50
C259, 260	ELECTR. CAPACITOR	CEAS2R2M50
C261, 262	CERAMIC CAPACITOR	CKCYB332K50
C263	ELECTR. CAPACITOR	CEAS330M35
C264-266	ELECTR. CAPACITOR	CEAS470M16

Mark No.	Description	Parts No.
RESISTORS		
VR201	VR (4.7k)	ACP1042
R263	CARBON FILM RESISTOR	RD1/4PM151J
	Other resistors	RD1/8PM□□□J
OTHERS		
	ANTENNA TERMINAL 4-P	AKA1009
	AM RF TUNING BLOCK	AXX1011
X201	CERAMIC RESONATOR (450kHz)	ATF1027
X202	CRYSTAL RESONATOR (7.200MHz)	ASS1005
SWITCH ASSEMBLY		
SEMICONDUCTORS		
D2062	LED (RED)	AEL1108
SWITCHES		
S2061	SWITCH (HIGH-SPEED COPY)	ASG1034
S2062	SWITCH (DOLBY NR ON/OFF)	ASH1014
RESISTORS		
	All resistors	RD1/8PM□□□J
DISPLAY ASSEMBLY		
SEMICONDUCTORS		
IC102	OP-AMP IC	RC4558DXP
IC103	DISPLAY IC	BA6144
IC105, 106	AUDIO IC	BA3812L
IC2061	OP-AMP IC	RC4558DXP
IC2101-2104	DISPLAY IC	BA6144
IC51	3IN1 SYSTEM CONTROL MICRO-COMPUTER	PDG079A
Q111	N-FET	2SK246
Q113-115	TRANSISTOR	2SC1740S
Q2061	TRANSISTOR	XDC124ES
Q2065, 2066	TRANSISTOR	2SC1740S
Q2101-2104	TRANSISTOR	2SC1740S
Q51	TRANSISTOR	XDA143ES
Q52	TRANSISTOR	2SD438
Q53	TRANSISTOR	2SB560
Q54	TRANSISTOR	2SC3377
Q55	TRANSISTOR	XDA143ES

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
Q56	TRANSISTOR	XDC143ES	C134	ELECTR. CAPACITOR	CEASR33M50
Q57	TRANSISTOR	XDC124ES	C135	ELECTR. CAPACITOR	CEAS100M50
Q58	TRANSISTOR	XDA143ES	C137, 138	ELECTR. CAPACITOR	CEAS4R7M50
Q59	TRANSISTOR	2SC1740S			
D101	DIODE	1SS252	C139—142	ELECTR. CAPACITOR	CEAS470M16
D2063	LED (RED)	AEL1108	C143, 144	CERAMIC CAPACITOR	CKCYF473Z50
D2105	LED	AEL1044	C2061, 2062	MYLAR FILM CAPACITOR	CQMA153J50
D51	DIODE	1SS252	C2063, 2064	MYLAR FILM CAPACITOR	CQMA823J50
D52	ZENER DIODE	RD10ESB1	C2101	CERAMIC CAPACITOR	CKCYX473M16
D53	ZENER DIODE	RD3.6ESB1			
D54	ZENER DIODE	RD11ESB2	C2103, 2104	CERAMIC CAPACITOR	CKCYX183M16
D55—59	LED (RED)	AEL1108	C2105	ELECTR. CAPACITOR	CEASR22M50
D60	LED (GREEN)	AEL1130	C2106	ELECTR. CAPACITOR	CEAS100M50
D61	ZENER DIODE	RD6.2ESB	C2107, 2108	CERAMIC CAPACITOR	CKCYB682K50
D62	DIODE	1SS252	C2109	CERAMIC CAPACITOR	CKCYX333M16
D63	LED (RED)	AEL1108			
D66	DIODE	1SS252	C2110	ELECTR. CAPACITOR	CEAS100M50
D67, 68	LED (RED)	AEL1108	C2111, 2112	CERAMIC CAPACITOR	CKCYB272K50
D69	DIODE	1SS252	C2113	CERAMIC CAPACITOR	CKCYX223M25
D71—73	ZENER DIODE	RD5.1ESB	C2114	ELECTR. CAPACITOR	CEAS100M50
SWITCHES			C2115, 2116	CERAMIC CAPACITOR	CKCYB821K50
S2063, 51	SWITCH (SUPER BASS, ASG1034 TAPE		C2117	CERAMIC CAPACITOR	CKCYB332K50
S53—62	SWITCH (ST. CALL, SURROUND & STEREO WIDE, TUNING UP, POWER/ STANDBY, MEMORY, TUNER, PHONO, TUNING DOWN, CD, BAND)	ASG1034	C2118	ELECTR. CAPACITOR	CEAS100M50
S64, 65	SWITCH (FM MONO, VOCAL CANCEL)	ASG1034	C50	ELECTR. CAPACITOR	CEAS4R7M50
			C51	CAPACITOR (47000/5.5)	ACH1135
COIL			C52	CERAMIC CAPACITOR	CKCYF473Z50
L51	AXIAL INDUCTOR	LAU220K	C53	ELECTR. CAPACITOR	CEAS470M16
CAPACITORS			C54	CERAMIC CAPACITOR	CKCYX104M16
C101, 102	CERAMIC CAPACITOR	CKCYX683M16	C55, 56	ELECTR. CAPACITOR	CEAS4R7M50
C103, 104	CERAMIC CAPACITOR	CGMYX392M25	RESISTORS		
C105, 106	CERAMIC CAPACITOR	CGMYB182M50	VR101—105	VR (100k-B5 × 2)	ACU1030
C107, 108	CERAMIC CAPACITOR	CKCYX153M16	R165	CARBON FILM RESISTOR	RD1/4PM101J
C109, 110	ELECTROLYTIC CAPACITOR	CEASR15M50	R2101, 2108	CARBON FILM RESISTOR	RD1/4PM390J
C111, 112	CERAMIC CAPACITOR	CKMYB391K50	R2115, 2122	CARBON FILM RESISTOR	RD1/4PM390J
C113, 114	CERAMIC CAPACITOR	CKCYX183M16	R2129	CARBON FILM RESISTOR	RD1/4PM390J
C115, 116	CERAMIC CAPACITOR	CGMYX682M25	R51—55	CARBON FILM RESISTOR	RD1/4PM270J
C117, 118	ELECTR. CAPACITOR	CEASR68M50	△ R79	METAL OXIDE RESISTOR	RS2LMF390J
C119, 120	CERAMIC CAPACITOR	CCDSL101J50	R91	CARBON FILM RESISTOR	RD1/4PM220J
C121, 122	CERAMIC CAPACITOR	CKCYX393M16		Other resistors	RD1/8PM□□□J
C123, 124	CERAMIC CAPACITOR	CCMSL121J50	OTHERS		
C125, 126	ELECTR. CAPACITOR	CEAS4R7M50		REMOTE RECEIVER UNIT	AXX1023
C127, 128	CERAMIC CAPACITOR	CKMYB471K50	V51	FL TUBE	AAV—039
C129	CERAMIC CAPACITOR	CKMYB681K50	X51	CERAMIC RESONATOR (4.00MHz)	ASS1025
C131, 132	CERAMIC CAPACITOR	CKCYX473M16			
C133	ELECTROLYTIC CAPACITOR	CEAS330M35			

Mark No.	Description	Parts No.
DOLBY ASSEMBLY		
SEMICONDUCTORS		
IC1201–1204	OP–AMP IC	RC4558DXP
IC1205	LOGIC IC	XRU4066B
IC1301	DOLBY–B IC	CXA1100P
IC1401	DIGITAL ECHO IC	M50197P
Q1204	TRANSISTOR	XDC143ES
Q1301–1305	TRANSISTOR	2SC1740S
Q1307	TRANSISTOR	2SC1740S
Q1309, 1310	TRANSISTOR	2SC1740S
D1301–1303	DIODE	1SS252
D1401–1404	DIODE	1SS252
COILS		
F1301, 1302	DOLBY FILTER	ATF1064
L1301, 1302	AXIAL INDUCTOR	LAU221K
L1401	AXIAL INDUCTOR	LAU221K
CAPACITORS		
C1203, 1204	CERAMIC CAPACITOR	CKCYX683M16
C1205, 1206	ELECTR. CAPACITOR	CEASR33M50
C1207, 1208	CERAMIC CAPACITOR	CKCYB272K50
C1209–1214	CERAMIC CAPACITOR	CKCYB561K50
C1215, 1216	ELECTR. CAPACITOR	CEAS4R7M50
C1217–1219	CERAMIC CAPACITOR	CKCYX183M16
C1220	CERAMIC CAPACITOR	CCCSL101J50
C1221, 1222	ELECTR. CAPACITOR	CEAS470M16
C1223, 1224	ELECTR. CAPACITOR	CEAS4R7M50
C1301–1304	ELECTR. CAPACITOR	CEAS010M50
C1305, 1306	ELECTR. CAPACITOR	CEASR68M50
C1307, 1308	ELECTR. CAPACITOR	CEAS2R2M50
C1309	ELECTR. CAPACITOR	CEAS100M50
C1310	ELECTR. CAPACITOR	CEAS220M50
C1311	ELECTR. CAPACITOR	CEAS470M16
C1312	ELECTR. CAPACITOR	CEAS101M10
C1313	CERAMIC CAPACITOR	CKCYF473Z50
C1315, 1316	CERAMIC CAPACITOR	CKCYX103M16
C1317, 1318	CERAMIC CAPACITOR	CKCYX333M16
C1319, 1320	CERAMIC CAPACITOR	CKCYX104M16
C1323, 1324	ELECTR. CAPACITOR	CEAS4R7M50
C1325, 1326	ELECTR. CAPACITOR	CEAS010M50
C1401	CERAMIC CAPACITOR	CKCYX104M16
C1402	ELECTR. CAPACITOR	CEAS010M50
C1403	CERAMIC CAPACITOR	CKCYB562K50
C1404	CERAMIC CAPACITOR	CKCYB561K50
C1405	ELECTR. CAPACITOR	CEANP010M50
C1406	CERAMIC CAPACITOR	CKCYX103M16
C1407	ELECTR. CAPACITOR	CEAS010M50
C1408	CERAMIC CAPACITOR	CKCYX103M16
C1409	CERAMIC CAPACITOR	CGMYX562M25
C1410	CERAMIC CAPACITOR	CKCYB561K50
C1411–1414	CERAMIC CAPACITOR	CKCYX104M16
C1415	ELECTR. CAPACITOR	CEAS101M10

Mark No.	Description	Parts No.
C1416	CERAMIC CAPACITOR	CKCYX104M16
C1417	ELECTR. CAPACITOR	CEAS470M16
C1418	ELECTR. CAPACITOR	CEAS101M10
C1419, 1420	CERAMIC CAPACITOR	CKCYX104M16
RESISTORS		
VR1301, 1302	VR	VRTM6H203
VR1303, 1304	VR	VRTM6H104
R1202	CARBON FILM RESISTOR	RD1/4PM221J
	Other resistors	RD1/8PM□□□J
OTHERS		
CN110	CONNECTOR (12P)	KPE12
CN2104	CONNECTOR (15P)	KPE15
X1401	CERAMIC OSCILLATOR (3.27MHz)	ASS1016
POWER ASSEMBLY		
SEMICONDUCTORS		
IC301	OP–AMP IC	RC4558DXP
IC302	LOGIC IC	MC14052BCP
IC303, 304	OP–AMP IC	RC4558DXP
IC306	OP–AMP IC	RC4558DXP
IC401	OP–AMP IC	RC4558DXP
IC402	OP–AMP IC	M5220P
IC404	LOGIC IC	XRU4066B
IC501, 502	IC PROTECTOR	ICP–N38
IC601, 602	REGULATOR IC	MC7812CT
Q2401, 2402	TRANSISTOR	2SC1740S
Q2403, 2404	TRANSISTOR	XDC143ES
Q2407	TRANSISTOR	XDA124ES
Q2408	TRANSISTOR	2SC1740S
Q2409	TRANSISTOR	XDC124ES
Q2410	TRANSISTOR	2SC1740S
Q305, 306	TRANSISTOR	2SC1740S
Q307	TRANSISTOR	RN2201
Q401, 402	N–FET	2SK373
Q403	TRANSISTOR	2SC1740S
Q405	TRANSISTOR	2SD438
Q406	TRANSISTOR	2SC1740S
Q407	TRANSISTOR	XDA124ES
Q408	TRANSISTOR	XDC124ES
Q411, 412	TRANSISTOR	2SC1740S
Q501–504	TRANSISTOR	2SA992
Q505, 506	TRANSISTOR	2SC1845
Q507, 508	TRANSISTOR	2SC1740S
Q509, 510	TRANSISTOR	2SD1276A
Q511, 512	TRANSISTOR	2SB950A
Q601	TRANSISTOR	2SA1048
Q602	TRANSISTOR	2SC1845
Q605	TRANSISTOR	2SC1740S

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
Q606	TRANSISTOR	2SA1048	C340	CERAMIC CAPACITOR	CKCYF473Z50
Q607, 608	TRANSISTOR	2SA1515	C401, 402	ELECTR. CAPACITOR	CEAS100M50
Q609	TRANSISTOR	XDC124ES	C403, 404	MYLAR FILM CAPACITOR	CQMA153J50
Q610	TRANSISTOR	2SB560	C405, 406	ELECTROLYTIC CAPACITOR	CEAS330M35
Q611	TRANSISTOR	2SB834	C407, 408	MYLAR FILM CAPACITOR	CQMA683J50
Q612, 613	TRANSISTOR	2SC1740S	C409, 410	MYLAR FILM CAPACITOR	CQMA272J50
Q614	TRANSISTOR	2SC3377	C411, 412	CERAMIC CAPACITOR	CKMYB681K50
Q615, 616	TRANSISTOR	XDC124ES	C413, 414	CERAMIC CAPACITOR	CCCSL271K500
Q621, 622	TRANSISTOR	2SC1740S	C415, 416	CERAMIC CAPACITOR	CCMSL100D50
D303	DIODE	1SS252	C417, 418	CERAMIC CAPACITOR	CKMYB471K50
D401—407	DIODE	1SS252	C419, 420	ELECTROLYTIC CAPACITOR	CEAS330M35
D408, 409	ZENER DIODE	RD5.1ESB	C421, 422	MYLAR FILM CAPACITOR	CQMA682J50
D501, 502	DIODE	1SS252	C423, 424	ELECTR. CAPACITOR	CEAS470M16
D503, 504	ZENER DIODE	RD4.3ESB	C427	CERAMIC CAPACITOR	CKCYF473Z50
D601, 602	ZENER DIODE	UZ—12BS	C428	ELECTR. CAPACITOR	CEAS220M50
D603	DIODE	1SS252	C433	ELECTR. CAPACITOR	CEAS47R7M50
D604	DIODE	D3SBA20 (A)	C437—440	CERAMIC CAPACITOR	CKCYX104M16
D605—608	DIODE	1SR139—400	C450	ELECTR. CAPACITOR	CEAS470M16
D609	ZENER DIODE	RD5.6ESB	C451	MYLAR FILM CAPACITOR	CQMA473K50
D610	ZENER DIODE	RD13ESB	C452	MYLAR FILM CAPACITOR	CQMA103K400
D611, 612	DIODE	1SR139—400	C453	MYLAR FILM CAPACITOR	CQMA333K250
D613	ZENER DIODE	RD20ESB	C501, 502	ELECTR. CAPACITOR	CEAS2R2M50
D614—618	DIODE	1SS252	C503, 504	CERAMIC CAPACITOR	CKCYB222K50
SWITCH & RELAY			C505, 506	ELECTR. CAPACITOR	CEAS470M25
S201	SLIDE SWITCH (9k/10k)	ASH1027	C507, 508	CERAMIC CAPACITOR	CCMSL680J50
RY601	RELAY	ASR1035	C509, 510	ELECTR. CAPACITOR	CEAS470M16
RY602	RELAY	ASR1027	C511, 512	CERAMIC CAPACITOR	CKMYB102K50
COILS			C513, 514	CERAMIC CAPACITOR	CCMSL101J50
L401, 402	INDUCTOR	LTA392J	C515—518	MYLAR FILM CAPACITOR	CQMA823K50
L403, 404	INDUCTOR	LTA822J	C519, 520	CERAMIC CAPACITOR	CCMSL680J50
L410	INDUCTOR	LTA102J	C521—524	CERAMIC CAPACITOR	CCMSL470J50
L501, 502	COIL	ATH—133	C525	CERAMIC CAPACITOR	CKCYX104M16
CAPACITORS			C601	ELECTR. CAPACITOR	CEAS00M50
C2301	ELECTR. CAPACITOR	CEAS100M50	C603	CKA (0.01/AC250V)	ACG105
C2401, 2402	MYLAR FILM CAPACITOR	CQMA822J50	C604—606	ELECTR. CAPACITOR (2200/42)	ACH109
C301, 302	CERAMIC CAPACITOR	CCMSL101J50	C607	ELECTROLYTIC CAPACITOR	CEAS02M35
C303, 304	CERAMIC CAPACITOR	CKMYB152K50	C608—611	ELECTR. CAPACITOR	CEAS70M16
C305, 306	CERAMIC CAPACITOR	CKCYB562K50	C612	ELECTR. CAPACITOR	CEAS21M16
C307, 308	ELECTR. CAPACITOR	CEAS3R3M50	C613	ELECTR. CAPACITOR	CEAS70M16
C309	CERAMIC CAPACITOR	CKCYX104M16	C614	ELECTR. CAPACITOR	CEAS01M50
C310	ELECTR. CAPACITOR	CEAS220M50	C615	ELECTR. CAPACITOR	CEAS01M63
C311, 312	ELECTR. CAPACITOR	CEAS470M16	C617	ELECTR. CAPACITOR	CEAS70M16
C313, 314	ELECTR. CAPACITOR	CEAS220M50	C618, 619	CKA (0.01/AC400V)	ACG103
C332, 333	CERAMIC CAPACITOR	CKCYF103Z50	C620	CKA (0.01/AC250V)	ACG105
C334, 335	CERAMIC CAPACITOR	CKCYF473Z50			
C336	CERAMIC CAPACITOR	CCMSL680J50			
C337	ELECTR. CAPACITOR	CEAS100M50			
C338	ELECTR. CAPACITOR	CEAS010M50			
C339	MYLAR FILM CAPACITOR	CQMA103K50			

Mark No.	Description	Parts No.
C621-624	ELECTROLYTIC CAPACITOR	CEAS472M25
C630	ELECTR. CAPACITOR	CEAS221M10
RESISTORS		
VR2301	VARIABLE (10k-B × 1)	ACS1064
VR2401, 2402	VR	VRTM6V103
VR2403	VR	VRTM6V104
VR2404	VR	VRTM6V502
VR301	VARIABLE (10k-B × 1)	ACS1064
VR401	VR	VRTM6V104
VR402	VR	VRTM6V502
R441	CARBON FILM RESISTOR	RD1/4PM471J
△ R442	METAL OXIDE RESISTOR	RS1LMF102J
R451	METAL OXIDE RESISTOR	RS2LMF470J
R454	CARBON FILM RESISTOR	RD1/4PM180J
R505, 506	CARBON FILM RESISTOR	RD1/4PM222J
R507, 508	CARBON FILM RESISTOR	RD1/4PM123J
R515-518	CARBON FILM RESISTOR	RD1/4PM222J
R523, 524	CARBON FILM RESISTOR	RD1/4PMF470J
R525, 526	CARBON FILM RESISTOR	RD1/4PM221J
R527-530	METAL OXIDE RESISTOR	RS2LMFR68J
R531, 532	CARBON FILM RESISTOR	RD1/4PMF100J
R535, 536	CARBON FILM RESISTOR	RD1/4PMFL100J
R573, 574	METAL OXIDE RESISTOR	RS2LMF010J
R601, 602	CARBON FILM RESISTOR	RD1/4PM100J
R603	METAL OXIDE RESISTOR	RS2LMF102J
R616	METAL OXIDE RESISTOR	RS2LMFR22J
R621	METAL OXIDE RESISTOR	RS2LMF101J
R624	METAL OXIDE RESISTOR	RS2LMF821J
R625	METAL OXIDE RESISTOR	RS2LMF221J
R626	METAL OXIDE RESISTOR	RS2LMF181J
R627	CARBON FILM RESISTOR	RD1/4PM682J
R633	METAL OXIDE RESISTOR	RS2LMF221J
R634	METAL OXIDE RESISTOR	RS2LMF681J

Mark No.	Description	Parts No.
R637	CARBON FILM RESISTOR	RD1/4PM3R9J
R638	METAL OXIDE RESISTOR	RS2LMF101J
R639, 640	CARBON FILM RESISTOR	RD1/4PM100J
	Other resistors	RD1/8PM□□□J
OTHERS		
	PIN JACK 2P (SURROUND)	AKB1100
	PIN JACK 4P (CD, PHONO)	AKB1124
	JACK (TURNTABLE)	AKN-203
	JACK (CONTROL)	AKN-207
	JACK (MIC)	AKN1017
CN	AC SOCKET 1-P SPEAKER TERMINAL 2-P	AKP1060 AKE1031
CN107	CONNECTOR (10P)	KPE10
CN108	CONNECTOR (11P)	KPE11
CN111	CONNECTOR (15P)	KPE15

HEADPHONE ASSEMBLY

RESISTORS

△ R533, 534	METAL OXIDE RESISTOR	RS1LMF331J
-------------	----------------------	------------

OTHERS

CN	JACK (HEADPHONE)	AKN1027
----	------------------	---------

TRANSE ASSEMBLY

TRANSE assembly has no service part.

4. ADJUSTMENTS

4.1 TUNER BLOCK

4.1.1 FM Tuner Block

- Set to the FM band.
 - Connect the tuner as shown in Fig. 4-1.
 - The adjustment locations and the TP terminals are in the TUNER assembly.
- *1 : Stereo modulation : Main 1kHz L+R ± 68.25 kHz dev.
Pilot 19kHz ± 6.75 kHz dev.

Step No.	Adjustment	FM SG (1kHz±75kHz dev.)		Reception frequency display	Adjustment location	Specifications						
		Frequency (MHz)	Level (dBμV)									
1	Adjustment of FM sensitivity	98	Low input	98MHz	T201	Adjust to maximize the output voltage of TP210 (Lch OUT) or TP212 (Rch OUT).						
2	Confirmation of 87.5MHz VT (tuning voltage)	No input		87.5MHz	—	Confirm that TP201 is 3.5V ±1.5V.						
3	Confirmation and adjustment of 108MHz VT (tuning voltage)			108MHz	L201	Confirm that TP201 is 8.7V $\pm_{1.3}$ V. Adjust at L201 only if the voltage is 10V or more.						
4	Adjustment of T-METER	98	60	98MHz	L202	Adjust so that the potential difference between TP202 and TP203 is 0V ±10mV.						
5	Adjustment of the TUNED IND. activation level.	98	See the table on the right.	98MHz	R265	R265 is either mounted or removed at adjustment before shipment. Refer to the table below and mount or remove R265 to align with the point at which the TUNED IND. lights up. <table><tr><td>R265</td><td>Input level</td></tr><tr><td>Required</td><td>25dBμV (±15dB)</td></tr><tr><td>Not required</td><td>More than 25dBμV (+15dB)</td></tr></table>	R265	Input level	Required	25dBμV (±15dB)	Not required	More than 25dBμV (+15dB)
R265	Input level											
Required	25dBμV (±15dB)											
Not required	More than 25dBμV (+15dB)											
6	Adjustment of MPX VCO	No modulation	80	98MHz	VR201	Adjust so that the frequency of TP205 is 76kHz ±100Hz.						
7	Adjustment of distortion	98 *1 (Stereo)	60	98MHz	T202	If distortion of TP210 (Lch OUT) or TP212 (Rch OUT) exceeds 1.5%, then adjust it at T202 to be 1.5% or less.						




Fig. 4-1 FM adjustment connection diagram

4.1.2 AM Tuner Block

- Set to the AM band.
- Connect the tuner as shown in Fig. 4–2.
- The adjustment locations and the TP terminals are in the TUNER assembly.

Step No.	Adjustment	AM SG (400Hz 30% Mod.)		Reception frequency display	Adjustment location	Specifications						
		Frequency (kHz)	Level (dBμV/m)									
1	Adjustment of the TUNED IND. activation level.	1000 *2	See the table on the right.	1000kHz	R232	R232 is either mounted or removed at adjustment before shipment. Refer to the table below and mount or remove R232 to align with the point at which the TUNED IND. lights up. <table><tr><td>R232</td><td>Input level</td></tr><tr><td>Required</td><td>60dBμV/m or less</td></tr><tr><td>Not required</td><td>More than 60dBμV/m</td></tr></table>	R232	Input level	Required	60dBμV/m or less	Not required	More than 60dBμV/m
R232	Input level											
Required	60dBμV/m or less											
Not required	More than 60dBμV/m											

*2 : This frequency applies to the areas classified as 10kHz step. For YPW and the areas of 9kHz step, perform adjustment at 999kHz.




Fig. 4–2 AM adjustment connection diagram

4.2 DECK BLOCK

4.2.1 Adjustment of Mechanical Section

- Test tape : STD-301 (3kHz 30min)
- Setting of high speed mode : Short-circuit TP409 and TP410 of the POWER assembly. To release the mode, disconnect the short circuit.

1. Adjustment of tape speed							
No.	Mode	Input signal & Test tape	Adjustment location		Measuring location	Adjustment value	Remarks
1	PLAY	Playback the STD-301 tape to 3kHz.	Deck I	POWER assembly VR402	POWER assembly TP401 (Lch)	Press the PLAY button and adjust the frequency to 3010Hz $\pm$ 10Hz. Make sure that the wow and flutter is within 0.3%.	
2	PLAY (High speed mode)			POWER assembly VR2404		Change to the high speed mode and press the PLAY button. Adjust the frequency to 6020Hz $\pm$ 20Hz.	

4.2.2 Adjustment of Electric Section

■ Check and conduct the following before adjusting the electric section.

1. Adjustment of tape speed has been completed.
2. Clean and demagnetize the head using a head eraser.
3. When measured, the level should be 0dBV = 1 Vrms.
4. Use side A of the specified tape for adjustment.
STD-331E : For adjustment of playback system.
STD-630 : NORMAL blank tape
5. Prepare the following measuring devices :
AC millivoltmeter, Low-frequency oscillator, Attenuator, Oscilloscope
6. Adjust both L and R channels, unless specified otherwise.
7. Set the DOLBY NR switches to OFF, VOCAL CANCEL to OFF (RX-Z35/SDXJ, YPWXJ) and MIC MIX to MIN (RX-Z35/SDXJ, YPWXJ).
8. Warm up the unit for several minutes before adjustment. Especially before adjusting the frequency characteristics of recording and playback, warm up for 3 to 5 minutes in REC/PLAY mode.
9. Make sure to follow the proper order of the adjustment procedure. Any change in the order may cause an improper result.

List of Adjustment

Deck I

1. Head azimuth adjustment
2. Playback level adjustment

Deck II

1. Head azimuth adjustment
2. Playback level adjustment
3. Recording level and bias level adjustment

NOTE :

As the reference recording level is 250nwb/m for STD-331E, the recording level will be higher by 4 dB for STD-331B (160nwb/m). When adjusting, pay carefull attention to the type of tape used.







Fig. 4-3 Test tape STD-331E

PLAY BACK



RECORDING



Azimuth adjustment screw

Fig. 4-4 Head azimuth adjustment

Fig. 4-5 Frequency characteristics

Head Adjustment of Deck I

1. Head Azimuth Adjustment

Pro-cedure	Tape selector	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (10kHz, -20dB).	Head azimuth adjustment screw (Fig. 4-4)	POWER assembly TP401 (Lch) TP403 (Rch)	Adjust so that the signal level is at maximum and the phase difference is zero (0).	Lock the screw with screw lock after completing adjustment.

2. Playback Level Adjustment

- Be sure to make a careful adjustment, as the adjustment determines the DOLBY NR level for playback.

Pro-cedure	Tape selector	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (315Hz, 0dB).	DOLBY assembly VR1301 (Lch) VR1302 (Rch)	POWER assembly TP401 (Lch) TP403 (Rch)	-1.2dBV ±0.5dB	

Head Adjustment of Deck II

1. Head Azimuth Adjustment

Pro-cedure	Tape selector	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (10kHz, -20dB).	Head azimuth adjustment screw (Fig. 4-4)	POWER assembly TP401 (Lch) TP403 (Rch)	Adjust so that the signal level is at maximum and the phase difference is zero (0).	Lock the screw with screw lock after completing adjustment.

2. Playback Level Adjustment

- Be sure to make a careful adjustment, as the adjustment determines the DOLBY NR level for playback.

Pro- cedure	Tape selector	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	PLAY	Playback the test tape STD-331E (315Hz, 0dB).	DOLBY assembly VR1303 (Lch) VR1304 (Rch)	POWER assembly TP401 (Lch) TP403 (Rch)	-1.2dBV $\pm$ 0.5dB	

3. Recording Level and Bias Level Adjustment

- Before starting adjustment, turn VR401 and VR2403 by 45 degrees counterclockwise from the mechanical center.

Pro- cedure	Tape selector	Mode	Input signal/test tape	Adjustment location	Measuring location	Adjustment value	Remarks
1	NORM	REC PAUSE	Inputs 315Hz to the CD RCA input terminal. Set the function to CD. Set test tape STD-630.	Input signal level	POWER assembly TP401 (Lch) TP403 (Rch)	Set the input signal to be -25.2dBV.	
2		REC/ PLAY	Record and playback the test tape STD-630.	POWER assembly VR2401 (Lch) VR2402 (Rch)		Repeat recording/playback until the playback level of 315Hz is -25.2dBV ±0.5dBV.	
3		REC PAUSE	Inputs 10kHz to the CD RCA input terminal. Set the function to CD. Set test tape STD-630.	Input signal level		Set the input signal to be -25.2dBV.	
4		REC/ PLAY	Record and playback the test tape STD-630.	POWER assembly VR401 (Lch) VR2403 (Rch)		Repeat recording/playback until the playback level of 10kHz is -25.2dBV ±0.5dBV.	
5	Repeat steps 1 to 4 and attain the best adjustment.						




Fig. 4-6-1 Adjustment points





Fig. 4-6-2 Adjustment points

4. REGLAGE

4.1 BLOC TUNER

5.1.1 Bloc Tuner FM

- Régler sur la gamme FM.
- Connecter le tuner de la manière illustrée à la Fig. 4-1.
- Les points de réglage et la borne TP sont situés dans l'ensemble TUNER.

*1 :
Modulation stéréo : Principal 1kHz L + R $\pm$ 68,25kHz dev.
Pilote 19kHz $\pm$ 6,75kHz dev.

Etape No.	Réglage	FM SG (1kHz±75kHz dév.)		Affichage de fréquence de réception	Lieu de réglage	Caractéristiques						
		Fréquence (MHz)	Niveau (dBμV)									
1	Réglage de la sensibilité FM	98	Entrée faible	98MHz	T201	Régler de manière à maximiser la tension de sortie de TP210 (SORTIE Canal L) et de TP212 (SORTIE canal R).						
2	Confirmation de VT (tension d'accord) à 87,5MHz.	Pas d'entrée		87,5MHz	—	Confirmer que TP201 est 3,5V ±1,5V.						
3	Confirmation et réglage de VT (tension d'accord) à 108MHz.			108MHz	L201	Confirmer que TP201 est 8,7V ±1,3 V. Régler au niveau de L201 uniquement si la tension est égale ou supérieure à 10V.						
4	Réglage de T – METER	98	60	98MHz	L202	Régler de manière que la différence de potentiel entre TP202 et TP203 soit de 0V ±10mV.						
5	Réglage du niveau d'activation de l'indicateur d'accord TUNED.	98	Voir la table ci-contre.	98MHz	R265	R265 est soit posé soit déposé lors du réglage en usine. Se reporter au tableau suivant et poser ou déposer R265 pour aligner le point auquel l'indicateur d'accord TUNED s'allume. <table><tr><td>R265</td><td>Niveau d'entrée</td></tr><tr><td>Requis</td><td>25dBμV (±15dB)</td></tr><tr><td>Non requis</td><td>25dBμV (+15dB) ou plus</td></tr></table>	R265	Niveau d'entrée	Requis	25dBμV (±15dB)	Non requis	25dBμV (+15dB) ou plus
R265	Niveau d'entrée											
Requis	25dBμV (±15dB)											
Non requis	25dBμV (+15dB) ou plus											
6	Réglage de MPX VCO	Pas de modulation	80	98MHz	VR201	Régler de manière que la fréquence de TP205 soit 76kHz ±100Hz.						
7	Réglage de la distorsion	98 *1 (Stéréo)	60	98MHz	T202	Si la distorsion entre TP210 (SORTIE Canal L) et TP212 (SORTIE canal R) dépasse 1.5%, régler au niveau de T202 de manière qu'elle soit égale ou inférieure à 1.5%.						




Fig. 4-1 Diagramme de connexion de réglage FM

4.1.2 Bloc Tuner AM

- Régler sur la gamme AM
- Connecter le tuner de la manière illustrée à la Fig. 4–2.
- Les points de réglage sont situés dans l'ensemble TUNER.

Etape No.	Réglage	AM SG (400Hz 30% Mod.)		Affichage de fréquence de réception	Lieu de réglage	Caractéristiques						
		Fréquence (kHz)	Niveau (dBµV/m)									
1	Réglage du niveau d'activation de l'indicateur d'accord TUNED.	1000 *2	Voir la table ci-contre.	1000kHz	R232	R232 est soit posé soit déposé lors du réglage en usine. Se reporter au tableau suivant et poser ou déposer R232 pour aligner le point auquel l'indicateur d'accord TUNED s'allume. <table><tr><td>R232</td><td>Niveau d'entrée</td></tr><tr><td>Requis</td><td>60dBµV/m ou moins</td></tr><tr><td>Non requis</td><td>Plus de 60dBµV/m</td></tr></table>	R232	Niveau d'entrée	Requis	60dBµV/m ou moins	Non requis	Plus de 60dBµV/m
R232	Niveau d'entrée											
Requis	60dBµV/m ou moins											
Non requis	Plus de 60dBµV/m											

*2 : Cette fréquence s'applique aux zones d'intervalle de 10kHz. Pour YPW et les zones d'intervalle de 9kHz, effectuer le réglage à 999kHz.




Fig. 4–2 Diagramme de connexion de réglage AM

4.2 BLOC AMPLI PLATINE

4.2.1 Réglages des parties mécaniques

- Bande d'étalonnage : STD-301 (3kHz, 30min.)
- Réglage du mode de vitesse double : Court-circuiter TP409 et TP410 de l'ensemble POWER. Pour libérer le mode, déconnecter le court-circuit.

1. Réglage de la vitesse de bande							
No.	Mode	Signal appliqué/bande d'étalonnage	Emplacement du réglage		Emplacement du point de mesure	Valeur relevée	Observations
1	PLAY	Reproduire la bande STD-301 par 3kHz.	Platine I	Ensemble POWER VR402	Ensemble POWER TP401 (can. G)	Appuyer sur la touche PLAY et régler la fréquence sur 3010Hz $\pm$ 10Hz. Vérifier que le pleurage et scintillement est dans la limite de 0,3%.	
2	PLAY (Mode de vitesse double)			Ensemble POWER VR2404		Passer au mode vitesse double et appuyer sur la touche PLAY. Régler la fréquence à 6020Hz $\pm$ 20Hz.	

4.2.2 Réglages des parties électriques

- Vérifier les points suivants et effectuer les opérations suivantes avant procéder aux réglages des parties électriques.

1. Le réglage de la vitesse de bande a été complété.
2. Nettoyer et démagnétiser la tête avec un démagnétiseur de tête.
3. Lors de la mesure, le niveau doit être de 0 dBV = 1 Vepp.
4. Utiliser la face A de la bande spécifiée pour le réglage.
STD-331E : Pour le réglage du système de lecture.
STD-630 : Bande vierge NORMAL
5. Préparer les instruments de mesure suivants:
Millivoltmètre CA, oscilateur à basse fréquence, éatténuateur et oscilloscope.
6. Régler les deux canaux L (gauche) et R (droit), sauf spécification contraire.
7. Régler les interrupteurs DOLBY NR sur OFF, VOCAL CANCEL sur OFF (RX-Z35/SDXJ, YPWXJ) et MIC MIX sur MIN (RX-Z35/SDXJ, YPWXJ).
8. Laisser chauffer l'appareil pendant plusieurs minutes avant le réglage. En particulier avant d'effectuer le réglage de la réponse en fréquence d'enregistrement et de lecture, laisser chauffer l'appareil pendant 3 à 5 minutes dans le mode d'enregistrement/lecture (REC/PLAY).
9. Toujours suivre l'ordre spécifié de la méthode de réglage. Tout changement de l'ordre peut provoquer des résultats incorrects.

Liste des réglages

Platine I

1. Azimut de la tête
2. Niveau de lecture

Platine II

1. Azimut de la tête
2. Niveau de lecture
3. Réglage du niveau d'enregistrement et du niveau de polarisation.

REMARQUE :

Le niveau d'enregistrement de référence étant de 250 nwb/m pour le STD-331E, le niveau d'enregistrement sera supérieur de 4 dB pour le STD-331B (160nwb/m). Pour le réglage, tenir compte du type de bande utilisé.





Fig. 4-3 Bande d'étalonnage STD-331E

LECTURE



ENREGISTREMENT




Fig. 4-5 Réponse en fréquence

Réglage de la Platine I

1. Réglage d'azimut de la tête

Opération	Sélecteur de bande	Mode	Signal appilégé / bande d'étalonnage	Emplacement du réglage	Emplacement du point de mesure	Valeur mesurée	Obserrations
1	NORM	PLAY	Reproduire la bande d'ééalonnfe STD-331E (10kHz, -20dB).	Vis de réglage d'ézimus de tête (Fig. 4-4)	Ensemble POWER TP401 (can. G) TP403 (can. D)	Régler de manière que le niveau du signal soit maximal et que différence de phase soit zéro (0).	Une fois le réglage terminé, bloquer la vis avec un frein de vis.

2. Réglage du niveau de lecture

- Toujours effectuer un réglage minutieux, car la valeur réglée sera le niveau Dolby pour la lecture.

Opération	Sélecteur de bande	Mode	Signal appilégé / bande d'étalonnage	Emplacement du réglage	Emplacement du point de mesure	Valeur mesurée	Obserrations
1	NORM	PLAY	Reproduire la bande d'ééalonnfe STD-331E (315kHz, 0dB)	Ensemble DOLBY VR1301 (can. G) VR1302 (can. D)	Ensemble POWER TP401 (can. G) TP403 (can. D)	-1,2dBV ±0.5dB	

■ Réglage de la Platine II

1. Réglage d'azimut de la tête

Opération	Sélecteur de bande	Mode	Signal appliqué / bande d'étalonnage	Emplacement du réglage	Emplacement du point de mesure	Valeur mesurée	Observations
1	NORM	PLAY	Reproduire la bande d'étalonnage STD-331E (10kHz, -20dB).	Vis de réglage d'azimut de tête (Fig. 4-4)	Ensemble POWER TP401 (can. G) TP403 (can. D)	Régler de manière que le niveau du signal soit maximal et que différence de phase soit zéro (0).	Une fois le réglage terminé, bloquer la vis avec un frein de vis.

2. Réglage du niveau de lecture

- Toujours effectuer un réglage minutieux, car la valeur réglée sera le niveau Dolby pour la lecture.

Opération	Sélecteur de bande	Mode	Signal appliqué / bande d'étalonnage	Emplacement du réglage	Emplacement du point de mesure	Valeur mesurée	Observations
1	NORM	PLAY	Reproduire la bande d'étalonnage STD-331E (315kHz, 0dB)	Ensemble DOLBY VR1303 (can. G) VR1304 (can. D)	Ensemble POWER TP401 (can. G) TP403 (can. D)	-1,2dBV $\pm$ 0.5dB	

3. Réglage du niveau d'enregistrement et du niveau de polarisation.

- Avant de procéder au réglage, tourner VR401 et VR2403 de 45 degrés dans le sens contraire des aiguilles d'une montre à partir du centre mécanique.

Opération	Sélecteur de bande	Mode	Signal appliqué / bande d'étalonnage	Emplacement du réglage	Emplacement du point de mesure	Valeur mesurée	Observations
1	NORM	REC PAUSE	Appliquer 315Hz à la borne IN de la broche CD RCA. Régler la fonction sur CD. Mettre en place la bande STD-630.	Niveau du signal d'entrée	Ensemble POWER TP401 (can. G) TP403 (can. D)	Régler le signal d'entrée à -25,2dBV.	
2		REC/PLAY	Enregistrer/reproduire STD-630.	Ensemble POWER VR2401 (can. G) VR2402 (can. D)		Répéter l'enregistrement/reproduction jusqu'à ce que le niveau de reproduction de 315Hz soit -25,2dBV ±0,5dBV.	
3		REC PAUSE	Appliquer 10kHz à la borne IN de la broche CD RCA. Régler la fonction sur CD. Mettre en place la bande STD-630.	Niveau du signal d'entrée		Régler le signal d'entrée à -25,2dBV.	
4		REC/PLAY	Enregistrer/reproduire STD-630.	Ensemble POWER VR401 (can. G) VR2403 (can. D)		Répéter l'enregistrement/reproduction jusqu'à ce que le niveau de reproduction de 10kHz soit -25,2dBV ±0,5dBV.	
5	Répéter les étapes 1 à 4 afin d'obtenir le meilleur réglage possible.						




Fig. 4-6 Points de réglage

4. AJUSTE

4.1 BLOQUE DEL SINTONIZADOR DE FM

4.1.1 Bloque del sintonizador de FM

- Ajuste a la banda de FM
- Conecte el sintonizador como se muestra en la Fig. 4-1.
- Las posiciones de ajuste y el terminal TP están en el conjunto del sintonizador (TUNER).

**1 :
Modulación estéreo : Principal 1kHz L + R $\pm$ 68,25kHz dev.
Piloto 19kHz $\pm$ 6,75kHz dev.*

N° de paso	Ajuste	FM SG (1kHz±75kHz dev.)		Fresuenci metro de recepción	Lugar de ajuste	Especificaciones						
		Frecuencia (MHz)	Nivel (dBμV)									
1	Ajuste de la sensibilidad de FM	98	Baja entrada	98MHz	T201	Ajuste para maximizar la tensión de salida de TP210 (L ch OUT) o TP 212 (R ch OUT).						
2	Confirmación de 87,5MHz VT (tensión de sintonización).	Sin entrada		87,5MHz	—	Confirme que TP201 sea 3,5V ±1,5V.						
3	Confirmación y ajuste de 108MHz VT (tensión de sintonización).			108MHz	L201	Confirme que TP201 sea 8,7V ±1,3 V. Ajuste en L201 sólo si la tensión es de 10V o más.						
4	Ajuste de T-METER	98	60	98MHz	L202	Ajuste de modo que la diferencia de potencial entre TP202 y TP203 sea 0V ±10mV.						
5	Ajuste del nivel de activación del indicador TUNED.	98	Vea la tabla de la derecha.	98MHz	R265	R265 está montado o extraído en el ajuste antes del embarque. Consulte la tabla siguiente y monte o extraiga R265 para alinear con el punto en el que se enciende el indicador TUNED. <table><tr><td>R265</td><td>Nivel de entrada</td></tr><tr><td>Requerido</td><td>25dBμV (±15dB)</td></tr><tr><td>No se requiere</td><td>25dBμV (±15dB) o más alto</td></tr></table>	R265	Nivel de entrada	Requerido	25dBμV (±15dB)	No se requiere	25dBμV (±15dB) o más alto
R265	Nivel de entrada											
Requerido	25dBμV (±15dB)											
No se requiere	25dBμV (±15dB) o más alto											
6	Ajuste de MPX VCO	Sin modulación	80	98MHz	VR201	Ajuste de modo que la frecuencia de TP205 sea 76kHz ±100Hz.						
7	Ajuste de la distorsión	98 *1 (Estéreo)	60	98MHz	T202	Si la distorsión de TP210 (Lch OUT) o TP212 (Rch OUT) excede el 1.5%, ajuste en T202 para ser del 1.5% o menos.						




Fig. 4-1 Diagrama de conexión de ajuste de FM

4.1.2 Bloque del sintonizador de AM

- Ajuste a la banda de AM
- Conecte el sintonizador como se muestra en la Fig. 4–2.
- Las posiciones de ajuste están en el conjunto del sintonizador (TUNER).

N° de paso	Ajuste	AM SG (400Hz 30% Mod.)		Fresuenci metro de recepción	Lugar de ajuste	Especificaciones						
		Frecuencia (kHz)	Nivel (dBµV/m)									
1	Ajuste del nivel de activación del indicador TUNED.	1000 *2	Vea la tabla de la izquierda.	1000kHz	R232	R232 está montado o extraído en el ajuste antes del embarque. Consulte la tabla siguiente y monte o extraiga R232 para alinear con el punto en el que se enciende el indicador TUNED. <table><tr><th>R232</th><th>Nivel de entrada</th></tr><tr><td>Requerido</td><td>60dBµV/m (± 15dB) o más bajo</td></tr><tr><td>No se requiere</td><td>Más alto que 60dBµV/m (± 15dB)</td></tr></table>	R232	Nivel de entrada	Requerido	60dBµV/m (± 15dB) o más bajo	No se requiere	Más alto que 60dBµV/m (± 15dB)
R232	Nivel de entrada											
Requerido	60dBµV/m (± 15dB) o más bajo											
No se requiere	Más alto que 60dBµV/m (± 15dB)											

*2 : Esta frecuencia se aplica a las áreas clasificadas como paso de 10kHz. Para YPW y las áreas de paso de 9kHz, efectúe el ajuste a 999kHz.




Fig. 4–2 Diagrama de conexión de ajuste de AM

4.2 BLOQUE DE AMPLIFICADOR DECK

4.2.1 Ajuste de la sección mecánica

- Cinta de prueba : STD-301 (3kHz, 30min)
- Ajuste del modo de velocidad doble : Cortocircuite TP409 y TP410 del conjunto del POWER. Para desactivar el modo, desconecte el cortocircuito.

1. Ajuste de la velocidad de la cinta							
N°	Modo	Señal de enerada/cinea de prueba	Punto de ajuste		Punto de medición	Valor de ajuste	Observaciones
1	PLAY	Reproducción de la cinta STD – 301 a 3kHz.	Sección I	VR402 del conjunto POWER	TP401 del conjunto POWER (canal izquierdo)	Presione el botón PLAY y ajuste la frecuencia a 3010Hz ± 10Hz. Cerciórese de que la fluctuación y el efecto de trémolo estén dentro de los límites del 0,3%.	
2	PLAY (Modo de velocidad doble)			VR2404 del conjunto POWER		Cambie al modo de velocidad doble y presione el botón PLAY. Ajuste la frecuencia a 6020Hz ± 20Hz.	

4.2.2 Ajuste de la sección eléctrica

- Antes de ajustar el sección eléctrica, compruebe y realice lo siguiente.

1. El ajuste de la velocidad de la cinta ha finalizado.
2. Limpie y desmagnetice la cabeza empleando un desmagnetizador de cabezas.
3. Cuando se mida, el nivel de nivel debe ser de $0\text{dBV} = 1\text{Vrms}$.
4. Emplee el lado A de la cinta especificada para realizar el ajuste.
STD-331E : Para ajuste del sistema de reproducción.
STD-630 : Cinta en blanco NORMAL
5. Prepare los dispositivos de medición siguientes :
Milivoltímetro de CA, oscilador de baja frecuencia, atenuador, y osciloscopio
6. Ajuste ambos canales, izquierdo y derecho, a menos que se especifique otra cosa.
7. Ajuste los interruptores DOLBY NR a OFF, VOCAL CANCEL a OFF (RX-Z35/SDXJ, YPWXJ), y MIC MIX a MIN (RX-Z35/SDXJ, YPWXJ).
8. Antes del ajuste, deje que la unidad se caliente durante varios minutos.
Especialmente antes de ajustar las características de frecuencia de grabación y reproducción, deje que se caliente durante 3 a 5 minutos en el modo REC/PLAY.
9. Cerciórese de seguir el orden apropiado del procedimiento de ajuste. Cualquier cambio en el orden podría causar un resultado inadecuado.

Lista de ajuste

Sección I

1. Azimut de la cabeza
2. Nivel de reproducción

Sección II

1. Azimut de la cabeza
2. Nivel de reproducción
3. Ajuste del nivel de grabación y nivel de polarización

NOTA :
Como el nivel de grabación de referencia es igual a 250 nwb/m para el STD-331E, el nivel de grabación será 4 dB mayor para el STD-331B (160 nwb/m). Al realizar el ajuste, preste suma atención al tipo de cinta que se está utilizando.





Fig. 4-3 Cinta de prueba STD-331E

REPRODUCCIÓN



GRABACIÓN





Fig. 4-5 Características de frecuencia



Tornillo de ajuste azimuth de REV

Fig. 4-4 Ajuste del azimuth de la cabeza

Ajuste de la sección I

1. Ajuste azimuthal de la cabeza

Procedi- miento	Selector de cinta	Modo	Señal de entrada / cinta de prueba	Punto de ajuste	Punto de medición	Valor de ajuste	Observaciones
1	NORM	PLAY	Ponga la cinta de prueba STD-331E en reproducción (10kHz, -20dB).	Tornillo de ajuste azimutal de la cabeza (Fig. 4-4)	Conjunto POWER TP401 (canal izquierdo) TP403 (canal derecho)	Ajuste de modo que el nivel de la señal sea el máximo y que la diferencia de fase sea cero (0).	Bloguee el tornillo con bloqueador de tornillos después de haber terminado el ajuste.

2. Ajuste del nivel de reproducción

- Tenga mucho cuidado durante el ajuste, ya que el valor ajustado será el nivel Dolby fijado para reproducción.

Procedi- miento	Selector de cinta	Modo	Señal de entrada / cinta de prueba	Punto de ajuste	Punto de medición	Valor de ajuste	Observaciones
1	NORM	PLAY	Ponga la cinta de prueba STD-331E en reproducción (315Hz, 0dB).	Conjunto DOLBY VR1301 (canal izquierdo) VR1302 (canal derecho)	Conjunto POWER TP401 (canal izquierdo) TP403 (canal derecho)	-1,2dBV ±0.5dB	

Ajuste de la sección II

1. Ajuste azimutal de la cabeza

Procedimiento	Selector de cinta	Modo	Señal de entrada / cinta de prueba	Punto de ajuste	Punto de medición	Valor de ajuste	Observaciones
1	NORM	PLAY	Ponga la cinta de prueba STD-331E en reproducción (10kHz, -20dB).	Tornillo de ajuste azimutal de la cabeza (Fig. 4-4)	Conjunto POWER TP401 (canal izquierdo) TP403 (canal derecho)	Ajuste de modo que el nivel de la señal sea el máximo y que la diferencia de fase sea cero (0).	Bloguee el tornillo con bloqueador de tornillos después de haber terminado el ajuste.

2. Ajuste del nivel de reproducción

- Tenga mucho cuidado durante el ajuste, ya que el valor ajustado será el nivel Dolby fijado para reproducción.

Procedimiento	Selector de cinta	Modo	Señal de entrada / cinta de prueba	Punto de ajuste	Punto de medición	Valor de ajuste	Observaciones
1	NORM	PLAY	Ponga la cinta de prueba STD-331E en reproducción (315Hz, 0dB).	Conjunto DOLBY VR1303 (canal izquierdo) VR1304 (canal derecho)	Conjunto POWER TP401 (canal izquierdo) TP403 (canal derecho)	-1,2dBV $\pm$ 0.5dB	

3. Ajuste el nivel de grabación y nivel de polarización

- Antes de iniciar el ajuste, gire 45 grados VR401 y VR403 hacia la izquierda partiendo del centro mecánico.

Procedimiento	Selector de cinta	Modo	Señal de entrada / cinta de prueba	Punto de ajuste	Punto de medición	Valor de ajuste	Observaciones
1	NORM	REC PAUSE	Introduce 315Hz en el terminal IN del tipo RCA de CD. Ajuste la función a CD. Ajuste la cinta STD-630.	Nivel de la señal de entrada	Conjunto POWER TP401 (canal izquierdo) TP403 (canal derecho)	Ajuste la señal de entrada para ser de -25,2dBV.	
2		REC/PLAY	Graba/reproduce la STD-630.	Conjunto POWER VR2401 (canal izquierdo) VR2402 (canal derecho)		Repita la grabación/reproducción hasta que el nivel de reproducción de 315Hz sea de -25,2dBV ±0,5dBV.	
3		REC PAUSE	Introduce 10kHz en el terminal IN del tipo RCA de CD. Ajuste la función a CD. Ajuste la cinta STD-630.	Nivel de la señal de entrada		Ajuste la señal de entrada para ser de -25,2dBV.	
4		REC/PLAY	Graba/reproduce la STD-630.	Conjunto POWER VR401 (canal izquierdo) VR2403 (canal derecho)		Repita la grabación/reproducción hasta que el nivel de reproducción de 10kHz sea de -25,2dBV ±0,5dBV.	
5	Repita los pasos 1 al 4 y realice el mejor ajuste.						




Fig. 4-6 Ponto de ajuste

5. IC INFORMATION

- The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.

■ IC1401 (M50197P) : 1-CHIP DIGITAL ECHO IC

● Pin Function

No.	Pin Name	I/O	Description	Standard output voltage
1	NC	—		—
2	VCC (analog power supply)	—	Applies 4.5 to 5.5V. (Rated voltage : 5V)	—
3	REF (reference)	—	Analog reference voltage $\approx 1/2V_{CC}$	2.5V
4	AGND (analog GND)	—		0V
5	DGND (digital GND)	—		0V
6	XOUT (oscillator output)	O		2.5V
7	XIN (oscillator input)	I		
8	$\mu\text{COM} / \overline{\text{EASY}}$	I	H = Microcomputer mode : Serial data control L = Easy mode : Parallel data control	—
9	VDD (digital power supply)	—	Applies 4.5 to 5.5V. (Rated voltage : 5V)	—
10	TEST	I	H = Test mode L = Normal mode	—
11	MODE	I	Changes mode *	—
12	REQ / DEL 1 (request/delay 1)	I	Microcomputer mode : Data request signal input Easy mode : Delay time setting *	—
13	REQ / DEL 2 (request/delay 2)	I		—
14	REQ / DEL 3 (request/delay 3)	I		—
15	MUTE	I	Mute control, H = Mute	—
16 25	NC	—		—
26	GC1 (gain control 1)	—	Gain control for Demodulator	0.6 V when no signal is input.
27	CC1 (current control 1)	—	ADM control for Demodulator	
28	GC0 (gain control)	—	Gain control for Modulator	
29	CC0 (current control)	—	ADM control for Modulator	
30	OP1 OUT (OP-AMP 1 output)	O	Configures the integrator for demodulator by external C.	2.5V
31	OP1 IN (OP-AMP 1 input)	I		2.5V

No.	Pin Name	I/O	Description	Standard output voltage
32	OP2 IN (OP-AMP 2 input)	I	Configures the integrator for modulator by external C.	2.5V
33	OP2 OUT (OP-AMP 2 output)	O		2.5V
34	LPF2 IN (low-pass filter 2 input)	I	Configures the low-pass filter on the output side by external CR.	2.5V
35	LPF2 OUT (low-pass filter 2 output)	O		2.5V
36	NC	—		—
37	ECHOFB (echo feedback)	O	Adjusts the amount of feedback during the echo mode. (Echo mode only)	2.5V
38	LPF1 OUT (low-pass filter 1 output)	O	Configures the low-pass filter on the input side by external CR.	2.5V
39	LPF1 IN (low-pass filter 1 input)	I		2.5V
40	NC	—		—

Note :

* : See below section "Operation".

● Operation

(1) Operation mode

MODE	Function	ECHOFB output
L	Surround mode	OFF
H	Echo mode	ON

(2) Delay time

DEL 1	DEL 2	DEL 3	Surround mode		Echo mode	
			fs	Td	fs	Td
L	L	L	500	4.1	250	20.5
H	H	L		10.2		41.0
H	L	L		14.3		61.4
L	H	L		20.5		81.9
H	L	H	500	24.6	125	98.3
L	L	H		30.7		122.9
L	H	H		34.8		139.3
H	H	H		41.0		163.8

fs = Sampling frequency (kHz)

Td = Delay time (msec)

■ PDG079A (IC51) : SYSTEM CONTROL MICRO-COMPUTER
● Pin Function

No.	Pin Name	I/O	Description
1	REC MUTE	O	REC MUTE ON/ $\overline{\text{OFF}}$
2	SURROUND	O	SURROUND ON/ $\overline{\text{OFF}}$
3	VOCAL CANCEL	O	VOCAL CANCEL ON/ $\overline{\text{OFF}}$ (RX-Z35/SDXJ, YPWXJ only)
4	STANDBY	O	POWER ON/ $\overline{\text{OFF}}$
5	S8	O	KEY SCAN OUTPUT (S8)
6	S9	O	KEY SCAN OUTPUT (S9)
7	S10	O	KEY SCAN OUTPUT (S10)
8	S11	O	KEY SCAN OUTPUT (S11)
9	S12	O	KEY SCAN OUTPUT (S12)
10	S13	O	KEY SCAN OUTPUT (S13)
11	S14	O	KEY SCAN OUTPUT (S14)
12	S15	O	KEY SCAN OUTPUT (S15)
13	S16/T15	O	SEGMENT OUTPUT (a)
14	S17/T14	O	SEGMENT OUTPUT (b)
15	S18/T13	O	SEGMENT OUTPUT (c)
16	S19/T12	O	SEGMENT OUTPUT (d)
17	S20/T11	O	SEGMENT OUTPUT (e)
18	S21/T10	O	SEGMENT OUTPUT (f)
19	S22/T9	O	SEGMENT OUTPUT (g)
20	S23/T8	O	SEGMENT OUTPUT (h)
21	T7	O	NOT USED (OPEN)
22	T6	O	NOT USED (OPEN)
23	T5	O	FL TIMING OUTPUT (1G)
24	T4	O	FL TIMING OUTPUT (2G)
25	T3	O	FL TIMING OUTPUT (3G)
26	T2	O	FL TIMING OUTPUT (4G)
27	T1	O	FL TIMING OUTPUT (5G)
28	T0	O	FL TIMING OUTPUT (6G)

No.	Pin Name	I/O	Description
29	9k/10k	I	Channel step frequency switching input (9/10 kHz)
30	XTAL	-	Connect a 4MHz ceramic oscillator.
31	EXTAL	-	
32	$\overline{\text{RST}}$	-	RESET INPUT
33	NC	-	NOT USED (OPEN)
34	VDD	-	+5V POWER SUPPLY INPUT
35	AD0/PI0	O	NOT USED (OPEN)
36	4052 B	O	4052 B OUTPUT
37	4052 A	O	4052 A OUTPUT
38	4052 INH	O	4052 INH OUTPUT
39	AD4/PB0	I	KEY SCAN PB0 INPUT
40	AD3/PB1	I	KEY SCAN PB1 INPUT
41	PLAY 1	I	DECK 1 PLAY $\overline{\text{ON/OFF}}$
42	PLAY 2	I	DECK 2 PLAY $\overline{\text{ON/OFF}}$
43	NC	-	NOT USED (OPEN)
44	LM7001 $\overline{\text{CLK}}$	O	SERIAL CLOCK OUTPUT
45	LM7001 DATA	O	SERIAL DATA OUTPUT
46	TUNED	I	TUNER TUNED SIGNAL INPUT
47	REC	I	DECK 2 REC $\overline{\text{ON/OFF}}$
48	HIGH SPEED COPY	I	HIGH SPEED COPY KEY INPUT
49	TEST MODE	I	TEST MODE ON/ $\overline{\text{OFF}}$
50	DOLBY MUTE	O	PB MUTE ON/ $\overline{\text{OFF}}$
51	BIAS OSC	O	BIAS OSC ON/ $\overline{\text{OFF}}$
52	LM7001 CE	O	PLL CHIP ENABLE
53	DECK 4066 CTRL	O	SELECT PB1/ $\overline{\text{PB2}}$

No.	Pin Name	I/O	Description
54	DOLBY P/R	O	SELECT DOLBY PB/REC
55	HIGH SPEED COPY	O	HIGH SPEED CONTROL HIGH/NORMAL
56	SUPER BASS (IND)	O	S. BASS LED ON/OFF (RX – Z35/SDXJ, YPWXJ only)
57	SUPER BASS	O	S. BASS CONTROL ON/OFF (RX – Z35/SDXJ, YPWXJ only)
58	PE3	O	NOT USED (OPEN)
59	VR UP	O	VOLUME UP
60	VR DOWN	O	VOLUME DOWN
61	STOP	I	AC DETECTION INPUT
62	REMOTE	I	REMOTE CONTROL SIGNAL INPUT
63	HIGH SPEED COPY (IND)	O	HIGH SPEED COPY LED ON/OFF
64	VOCAL CANCEL (IND)	O	VOCAL CANCEL LED ON/OFF (RX – Z35/SDXJ, YPWXJ only)
65	SURROUND (IND)	O	SURROUND LED ON/OFF
66	PHONO (IND)	O	FUNCTION PHONO LED ON/OFF
67	CD (IND)	O	FUNCTION CD LED ON/OFF
68	TUNER (IND)	O	FUNCTION TUNER LED ON/OFF
69	STANDBY (IND)	O	STANDBY LED ON/OFF
70	TAPE (IND)	O	FUNCTION TAPE LED ON/OFF
71	Vss	–	Connect to GND
72	TX	–	NOT USED (OPEN)
73	NC	–	NOT USED (OPEN)
74	TEX	–	Connect to Vdd or GND

No.	Pin Name	I/O	Description
75	VREF	–	Connect to Vdd
76	VFDP	–	–18V FDP LOAD POWER INPUT
77	MUTE	O	LINE MUTE ON/OFF
78	SPEANA MUTE	O	SPECTRUM ANALYZER MUTE
79	FL OFF	O	FL ON/OFF
80	MUTE RY	O	PROTECTION-RELAY ON/OFF

6. FOR RX – Z35/YPWXJ AND RX – Z45/HEXJ TYPES

NOTES:

- Parts marked by “NSP” are generally unavailable because they are not in our Master Spare Parts List.
- The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by “ $\odot$ ” are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

6.1 CONTRAST OF MISCELLANEOUS PARTS

RX – Z35/YPWXJ, RX – Z45/HEXJ and RX – Z35/SDXJ have the same construction except for the following :

Mark	Symbol & Description	Part No.			Remarks
		RX – Z35/ SDXJ type	RX – Z35/ YPWXJ type	RX – Z45/ HEXJ type	
$\odot$	DISPLAY assembly	AWZ3837	AWZ3837	AWZ3965	
$\odot$	DOLBY assembly	AWZ3967	AWZ3967	AWZ3968	
$\odot$	POWER assembly	AWZ3832	AWZ4157	AWZ3969	
$\triangle$	S1 Voltage selector (AC110V/120 – 127V/220V/240V)	AKX – 507			
$\triangle$	T1 Power transformer	ATS1389	ATS1398	ATS1398	
$\triangle$	FU602 Fuse (T800mA/125V)	AEK – 507		AEK – 507	
$\triangle$	AC Power cord	ADG1051	ADG1050	ADG1049	
$\triangle$	AC Outlet 1P		AKP – 517	AKP – 508	
NSP NSP	MIXING knob	AAB1265	AAB1265		
	P. BASS button	AAD2125	AAD2125		
	Front panel	AMB1947	AMB1947	AMB1948	
	Rear panel	ANC1837	ANC1838	ANC1839	
	Jack holder	ANG1613	ANG1613		
	Packing case	AHD2209	AHD2209	AHD2235	
	Operating instructions (Spanish)	ARC1322			
	Operating instructions (French, Dutch, Spanish, Portuguese)			ARE1220	
	Remote control unit (CU – RX011)	AXD1257	AXD1257		
	Remote control unit (CU – RX010)			AXD1256	

POWER ASSEMBLY (RX – Z35/YPWXJ)

POWER assembly (AWZ4157) and POWER assembly (AWZ3832) have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ3832	AWZ4157	
△	AC SOCKET 1-P	AKP1060		

6.2 PCB PARTS LIST (RX – Z45/HEXJ)

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The △ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560Ω → 56 × 10¹ → 561 RD1/8PM 5 6 1 J
47kΩ → 47 × 10³ → 473 RD1/4PS 4 7 3 J
0.5Ω → 0R5 RN2H 0 5 K
1Ω → 010 RSIP 0 1 0 K

Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ → 562 × 10¹ → 5621 RN1/4PC 5 6 2 1 F

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.
LIST OF ASSEMBLIES				Q53		TRANSISTOR	2SB50
NSP		VOLUME ASSEMBLY	AWZ3829	Q54		TRANSISTOR	2SC377
●		TUNER ASSEMBLY	AWZ3835	Q55		TRANSISTOR	XDA143ES
NSP		SWITCH ASSEMBLY	AWZ3836	Q56		TRANSISTOR	XDC143ES
●		DISPLAY ASSEMBLY	AWZ3965	Q57		TRANSISTOR	XDC144ES
●		DOLBY ASSEMBLY	AWZ3968				
●		POWER ASSEMBLY	AWZ3969	Q58		TRANSISTOR	XDA143ES
NSP		HEADPHONE ASSEMBLY	AWZ3834	Q59		TRANSISTOR	2SC1740S
NSP		TRANSE ASSEMBLY	AWZ3863	D101		DIODE	1SS25
DISPLAY ASSEMBLY				D2105		LED	AEL1044
SEMICONDUCTORS				D51		DIODE	1SS25
IC102		OP-AMP IC	RC4558DXP	D52		ZENER DIODE	RD10ESB1
IC103		DISPLAY IC	BA6144	D53		ZENER DIODE	RD3.6SB1
IC105, 106		AUDIO IC	BA3812L	D54		ZENER DIODE	RD11ESB2
IC2101-2104		DISPLAY IC	BA6144	D55-59		LED (RED)	AEL1108
IC51		3IN1 SYSTEM CONTROL MICRO-COMPUTER	PDG079A	D60		LED (GREEN)	AEL1130
Q111		N-FET	2SK246	D61		ZENER DIODE	RD6.2ESB
Q113-115		TRANSISTOR	2SC1740S	D62, 66		DIODE	1SS25
Q2101-2104		TRANSISTOR	2SC1740S	D67, 68		LED (RED)	AEL1108
Q51		TRANSISTOR	XDA143ES	D69		DIODE	1SS25
Q52		TRANSISTOR	2SD438	D71-73		ZENER DIODE	RD5.1ESB

Mark No.	Description	Parts No.
SWITCHES		
S51	SWITCH (TAPE)	ASG1034
S53—62	SWITCH (ST. CALL, SURROUND & STEREO WIDE, TUNING UP, POWER/STANDBY, MEMORY, TUNER, PHONO, TUNING DOWN, CD, BAND)	ASG1034
S64	SWITCH (FM MONO)	ASG1034
COILS		
L51	AXIAL INDUCTOR	LAU220K
CAPACITORS		
C101, 102	CERAMIC CAPACITOR	CKCYX683M16
C103, 104	CERAMIC CAPACITOR	CGMYX392M25
C105, 106	CERAMIC CAPACITOR	CGMYB182M50
C107, 108	CERAMIC CAPACITOR	CKCYX153M16
C109, 110	ELECTR. CAPACITOR	CEASR15M50
C111, 112	CERAMIC CAPACITOR	CKMYB391K50
C113, 114	CERAMIC CAPACITOR	CKCYX183M16
C115, 116	CERAMIC CAPACITOR	CGMYX682M25
C117, 118	ELECTR. CAPACITOR	CEASR68M50
C119, 120	CERAMIC CAPACITOR	CCDSL101J50
C121, 122	CERAMIC CAPACITOR	CKCYX393M16
C123, 124	CERAMIC CAPACITOR	CCMSL121J50
C125, 126	ELECTR. CAPACITOR	CEAS4R7M50
C127, 128	CERAMIC CAPACITOR	CKMYB471K50
C129	CERAMIC CAPACITOR	CKMYB681K50
C131, 132	CERAMIC CAPACITOR	CKCYX473M16
C133	ELECTR. CAPACITOR	CEAS330M35
C134	ELECTR. CAPACITOR	CEASR33M50
C135	ELECTR. CAPACITOR	CEAS100M50
C137, 138	ELECTR. CAPACITOR	CEAS4R7M50
C139—142	ELECTR. CAPACITOR	CEAS470M16
C143, 144	CERAMIC CAPACITOR	CKCYF473Z50
C2101	CERAMIC CAPACITOR	CKCYX473M16
C2103, 2104	CERAMIC CAPACITOR	CKCYX183M16
C2105	ELECTR. CAPACITOR	CEASR22M50
C2106	ELECTR. CAPACITOR	CEAS100M50
C2107, 2108	CERAMIC CAPACITOR	CKCYB682K50
C2109	CERAMIC CAPACITOR	CKCYX333M16
C2110	ELECTR. CAPACITOR	CEAS100M50
C2111, 2112	CERAMIC CAPACITOR	CKCYB272K50
C2113	CERAMIC CAPACITOR	CKCYX223M25
C2114	ELECTR. CAPACITOR	CEAS100M50
C2115, 2116	CERAMIC CAPACITOR	CKCYB821K50
C2117	CERAMIC CAPACITOR	CKCYB332K50
C2118	ELECTR. CAPACITOR	CEAS100M50
C50	ELECTR. CAPACITOR	CEAS4R7M50
C51	CAPACITOR (47000/5.5)	ACH1135
C52	CERAMIC CAPACITOR	CKCYF473Z50
C53	ELECTR. CAPACITOR	CEAS470M16
C54	CERAMIC CAPACITOR	CKCYX104M16
C55, 56	ELECTR. CAPACITOR	CEAS4R7M50

Mark No.	Description	Parts No.
RESISTORS		
VR101—105	VR (100k-B5×2)	ACU1030
R165	CARBON FILM RESISTOR	RD1/4PM101J
R2101	CARBON FILM RESISTOR	RD1/4PM390J
R2108	CARBON FILM RESISTOR	RD1/4PM390J
R2115	CARBON FILM RESISTOR	RD1/4PM390J
R2122	CARBON FILM RESISTOR	RD1/4PM390J
R2129	CARBON FILM RESISTOR	RD1/4PM390J
R51—55	CARBON FILM RESISTOR	RD1/4PM270J
△ R79	METAL OXIDE RESISTOR	RS2LMF390J
R91	CARBON FILM RESISTOR	RD1/4PM220J
	Other resistors	RD1/8PM□□□J
OTHERS		
	REMOTE RECEIVER UNIT	AXX1023
V51	FL TUBE	AAV—039
X51	CERAMIC RESONATOR (4.00MHz)	ASS1025
DOLBY ASSEMBLY		
SEMICONDUCTORS		
IC1301	DOLBY—B IC	CXA1100P
Q1301—1305	TRANSISTOR	2SC1740S
Q1307	TRANSISTOR	2SC1740S
Q1309, 1310	TRANSISTOR	2SC1740S
D1301—1303	DIODE	1SS252
COILS		
F1301, 1302	DOLBY FILTER	ATF1064
L1301	AXIAL INDUCTOR	LAU221K
L1302	AXIAL INDUCTOR	LAU221K
CAPACITORS		
C1301—1304	ELECTR. CAPACITOR	CEAS010M50
C1305, 1306	ELECTR. CAPACITOR	CEASR68M50
C1307, 1308	ELECTR. CAPACITOR	CEAS2R2M50
C1309	ELECTR. CAPACITOR	CEAS100M50
C1310	ELECTR. CAPACITOR	CEAS220M50
C1311	ELECTR. CAPACITOR	CEAS470M16
C1312	ELECTR. CAPACITOR	CEAS101M10
C1313	CERAMIC CAPACITOR	CKCYF473Z50
C1315, 1316	CERAMIC CAPACITOR	CKCYX103M16

Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.	Mark	No.	Description	Parts No.	M
	C1317, 1318	CERAMIC CAPACITOR	CKCYX333M16		Q612, 613	TRANSISTOR	2SC1740S		C417, 418	CERAMIC CAPACITOR	CKMYB471K50		R454	CARBON FILM RESISTOR	RD1/4PM180J	O
	C1319, 1320	CERAMIC CAPACITOR	CKCYX104M16		Q614	TRANSISTOR	2SC3377		C419, 420	ELECTR. CAPACITOR	CEAS330M35		R505, 506	CARBON FILM RESISTOR	RD1/4PM222J	
	C1323, 1324	ELECTR. CAPACITOR	CEAS4R7M50		Q615, 616	TRANSISTOR	XDC124ES		C421, 422	MYLAR FILM CAPACITOR	CQMA682J50					
	C1325, 1326	ELECTR. CAPACITOR	CEAS010M50		Q621, 622	TRANSISTOR	2SC1740S		C423, 424	ELECTR. CAPACITOR	CEAS470M16		R507, 508	CARBON FILM RESISTOR	RD1/4PM123J	
RESISTORS					D303	DIODE	1SS252		C427	CERAMIC CAPACITOR	CKCYF473Z50		R515-518	CARBON FILM RESISTOR	RD1/4PM222J	
	VR1301, 1302	VR	VRTM6H203		D401-407	DIODE	1SS252		C428	ELECTR. CAPACITOR	CEAS220M50					
	VR1303, 1304	VR	VRTM6H104		D408, 409	ZENER DIODE	RD5.1ESB		C433	ELECTR. CAPACITOR	CEAS4R7M50	△	R523, 524	CARBON FILM RESISTOR	RD1/4PMF470J	
	Other resistors		RD1/8PM□□□J		D501, 502	DIODE	1SS252		C437-440	CERAMIC CAPACITOR	CKCYX104M16		R525, 526	CARBON FILM RESISTOR	RD1/4PM221J	
OTHERS					D503, 504	ZENER DIODE	RD4.3ESB		C450	ELECTR. CAPACITOR	CEAS470M16		△	R527-530	METAL OXIDE RESISTOR	RS2LMFR68J
	CN2104	CONNECTOR (15P)	KPE15		D601, 602	ZENER DIODE	UZ-12BS		C451	MYLAR FILM CAPACITOR	CQMA473K50					
					D603	DIODE	1SS252		C452	MYLAR FILM CAPACITOR	CQMA103K400	△	R531, 532	CARBON FILM RESISTOR	RD1/4PMF100J	Th.
POWER ASSEMBLY					D604	DIODE	D3SBA20 (A)						R535, 536	CARBON FILM RESISTOR	RD1/4PMFL100J	RX
SEMICONDUCTORS					D605-608	DIODE	1SR139-400		C453	MYLAR FILM CAPACITOR	CQMA333K250	△	R573, 574	METAL OXIDE RESISTOR	RS2LMF010J	
	IC301	OP-AMP IC	RC4558DXP		D609	ZENER DIODE	RD5.6ESB		C501, 502	ELECTR. CAPACITOR	CEAS2R2M50		R601, 602	CARBON FILM RESISTOR	RD1/4PM100J	
	IC302	LOGIC IC	MC14052BCP		D610	ZENER DIODE	RD13ESB		C503, 504	CERAMIC CAPACITOR	CKCYB222K50	△	R603	METAL OXIDE RESISTOR	RS2LMF102J	
	IC303, 304	OP-AMP IC	RC4558DXP		D611, 612	DIODE	1SR139-400		C505, 506	ELECTR. CAPACITOR	CEAS470M25					
	IC401	OP-AMP IC	RC4558DXP		D613	ZENER DIODE	RD20ESB		C507, 508	CERAMIC CAPACITOR	CCMSL680J50	△				
	IC402	OP-AMP IC	M5220P		D614-618	DIODE	1SS252		C509, 510	ELECTR. CAPACITOR	CEAS470M16					
	IC404	LOGIC IC	XRU4066B						C511, 512	CERAMIC CAPACITOR	CKMYB102K50	△	R616	METAL OXIDE RESISTOR	RS2LMFR22J	
△	IC501, 502	IC PROTECTOR	ICP-N38		SWITCH & RELAIES				C513, 514	CERAMIC CAPACITOR	CCMSL101J50		△	R621	METAL OXIDE RESISTOR	RS2LMF101J
	IC601, 602	REGULATOR IC	MC7812CT		S201	SLIDE SWITCH (9k/10k)	ASH1027		C515-518	MYLAR FILM CAPACITOR	CQMA823K50			R624	METAL OXIDE RESISTOR	RS2LMF821J
	Q2401, 2402	TRANSISTOR	2SC1740S		RY601	RELAY	ASR1035		C519, 520	CERAMIC CAPACITOR	CCMSL680J50	△	R625	METAL OXIDE RESISTOR	RS2LMF221J	
	Q2403	TRANSISTOR	XDC143ES	△	RY602	RELAY	ASR1027					△	R626	METAL OXIDE RESISTOR	RS2LMF181J	
	Q2407	TRANSISTOR	XDA124ES		COILS				C521-524	CERAMIC CAPACITOR	CCMSL470J50			R627	CARBON FILM RESISTOR	RD1/4PM682J
	Q2408	TRANSISTOR	2SC1740S		L401, 402	INDUCTOR	LTA392J		C525	CERAMIC CAPACITOR	CKCYX104M16	△		R633	METAL OXIDE RESISTOR	RS2LMF221J
	Q2409	TRANSISTOR	XDC124ES		L403, 404	INDUCTOR	LTA822J		C601	ELECTR. CAPACITOR	CEAS100M50		△	R634	METAL OXIDE RESISTOR	RS2LMF681J
					L410	INDUCTOR	LTA102J		C603	CKA (0.01/AC250V)	ACG1005			R637	CARBON FILM RESISTOR	RD1/4PM3R9J
					L501, 502	COIL	ATH-133		C604-606	ELECTR. CAPACITOR (2200/42)	ACH1109	△	△	R638	METAL OXIDE RESISTOR	RS2LMF101J
	Q2410	TRANSISTOR	2SC1740S		CAPACITORS								R639, 640	CARBON FILM RESISTOR	RD1/4PM100J	
	Q305, 306	TRANSISTOR	2SC1740S		C2401, 2402	MYLAR FILM CAPACITOR	CQMA153J50		C607	ELECTR. CAPACITOR	CEAS102M35			Other resistors	RD1/8PM□□□J	
	Q307	TRANSISTOR	RN2201		C301, 302	CERAMIC CAPACITOR	CCMSL101J50		C608-611	ELECTR. CAPACITOR	CEAS470M16					
	Q401, 402	N-FET	2SK373		C303, 304	CERAMIC CAPACITOR	CKMYB152K50		C612	ELECTR. CAPACITOR	CEAS221M16	△				
	Q403	TRANSISTOR	2SC1740S		C305, 306	CERAMIC CAPACITOR	CKCYB562K50		C613	ELECTR. CAPACITOR	CEAS470M16					
	Q405	TRANSISTOR	2SD438		C307, 308	ELECTR. CAPACITOR	CEAS3R3M50		C614	ELECTR. CAPACITOR	CEAS101M50	△				
	Q406	TRANSISTOR	2SC1740S						C615	ELECTR. CAPACITOR	CEAS101M63					
	Q407	TRANSISTOR	XDA124ES		C309	CERAMIC CAPACITOR	CKCYX104M16		C617	ELECTR. CAPACITOR	CEAS470M16					
	Q408	TRANSISTOR	XDC124ES		C310	ELECTR. CAPACITOR	CEAS220M50		△	C618, 619	CKA (0.01/AC400V)	ACG1003				
	Q411, 412	TRANSISTOR	2SC1740S		C311, 312	ELECTR. CAPACITOR	CEAS470M16		C620	CKA (0.01/AC250V)	ACG1005	△				
	Q501-504	TRANSISTOR	2SA992		C313, 314	ELECTR. CAPACITOR	CEAS220M50		C621-624	ELECTR. CAPACITOR	CEAS472M25					
	Q505, 506	TRANSISTOR	2SC1845		C332, 333	CERAMIC CAPACITOR	CKCYF103Z50		C630	ELECTR. CAPACITOR	CEAS221M10					
	Q507, 508	TRANSISTOR	2SC1740S						RESISTORS							
	Q509, 510	TRANSISTOR	2SD1276A		C340	CERAMIC CAPACITOR	CKCYF473Z50		VR2401, 2402	VR	VRTM6V103					
	Q511, 512	TRANSISTOR	2SB950A		C401, 402	ELECTR. CAPACITOR	CEAS100M50		VR2403	VR	VRTM6V104					
					C403, 404	MYLAR FILM CAPACITOR	CQMA153J50		VR2404	VR	VRTM6V502					
	Q601	TRANSISTOR	2SA1048		C405, 406	ELECTR. CAPACITOR	CEAS330M35		VR401	VR	VRTM6V104					
	Q602	TRANSISTOR	2SC1845		C407, 408	MYLAR FILM CAPACITOR	CQMA683J50		VR402	VR	VRTM6V502					
	Q605	TRANSISTOR	2SC1740S													
	Q606	TRANSISTOR	2SA1048		C409, 410	MYLAR FILM CAPACITOR	CQMA272J50		R441	CARBON FILM RESISTOR	RD1/4PM471J					
	Q607, 608	TRANSISTOR	2SA1515		C411, 412	CERAMIC CAPACITOR	CKMYB681K50		△	R442	METAL OXIDE RESISTOR	RS1LMF102J				
	Q609	TRANSISTOR	XDC124ES		C413, 414	CERAMIC CAPACITOR	CCCSL271K500		△	R451	METAL OXIDE RESISTOR	RS2LMF470J				
	Q610	TRANSISTOR	2SB560		C415, 416	CERAMIC CAPACITOR	CCMSL100D50									
	Q611	TRANSISTOR	2SB834													

No.	Mark No.	Description	Parts No.
740S 377	C417, 418	CERAMIC CAPACITOR	CKMYB471K50
24ES 740S	C419, 420	ELECTR. CAPACITOR	CEAS330M35
2 2	C421, 422	MYLAR FILM CAPACITOR	CQMA682J50
ESB 2 ESB	C423, 424	ELECTR. CAPACITOR	CEAS470M16
2BS 2 A20 (A) 9-400 ESB	C427	CERAMIC CAPACITOR	CKCYF473Z50
	C428	ELECTR. CAPACITOR	CEAS220M50
CSB 9-400 CSB 2	C433	ELECTR. CAPACITOR	CEAS4R7M50
27	C437-440	CERAMIC CAPACITOR	CKCYX104M16
35 27	C450	ELECTR. CAPACITOR	CEAS470M16
2J 2J 2J 133	C451	MYLAR FILM CAPACITOR	CQMA473K50
153J50 101J50 3152K50 562K50 R3M50 104M16 20M50 70M16 20M50 103Z50	C452	MYLAR FILM CAPACITOR	CQMA103K400
	C453	MYLAR FILM CAPACITOR	CQMA333K250
	C501, 502	ELECTR. CAPACITOR	CEAS2R2M50
	C503, 504	CERAMIC CAPACITOR	CKCYB222K50
	C505, 506	ELECTR. CAPACITOR	CEAS470M25
	C507, 508	CERAMIC CAPACITOR	CCMSL680J50
	C509, 510	ELECTR. CAPACITOR	CEAS470M16
	C511, 512	CERAMIC CAPACITOR	CKMYB102K50
	C513, 514	CERAMIC CAPACITOR	CCMSL101J50
	C515-518	MYLAR FILM CAPACITOR	CQMA823K50
	C519, 520	CERAMIC CAPACITOR	CCMSL680J50
	C521-524	CERAMIC CAPACITOR	CCMSL470J50
	C525	CERAMIC CAPACITOR	CKCYX104M16
	C601	ELECTR. CAPACITOR	CEAS100M50
	C603	CKA (0.01/AC250V)	ACG1005
	C604-606	ELECTR. CAPACITOR (2200/42)	ACH1109
	C607	ELECTR. CAPACITOR	CEAS102M35
	C608-611	ELECTR. CAPACITOR	CEAS470M16
	C612	ELECTR. CAPACITOR	CEAS221M16
	C613	ELECTR. CAPACITOR	CEAS470M16
	C614	ELECTR. CAPACITOR	CEAS101M50
	C615	ELECTR. CAPACITOR	CEAS101M63
	C617	ELECTR. CAPACITOR	CEAS470M16
	C618, 619	CKA (0.01/AC400V)	ACG1003
	C620	CKA (0.01/AC250V)	ACG1005
	C621-624	ELECTR. CAPACITOR	CEAS472M25
	C630	ELECTR. CAPACITOR	CEAS221M10
	RESISTORS		
	VR2401, 2402	VR	VRTM6V103
	VR2403	VR	VRTM6V104
	VR2404	VR	VRTM6V502
	VR401	VR	VRTM6V104
	VR402	VR	VRTM6V502
72J50	R441	CARBON FILM RESISTOR	RD1/4PM471J
681K50 71K500 100D50	R442	METAL OXIDE RESISTOR	RS1LMF102J
	R451	METAL OXIDE RESISTOR	RS2LMF470J


Mark No.	Description	Parts No.
R454	CARBON FILM RESISTOR	RD1/4PM180J
R505, 506	CARBON FILM RESISTOR	RD1/4PM222J
R507, 508	CARBON FILM RESISTOR	RD1/4PM123J
R515-518	CARBON FILM RESISTOR	RD1/4PM222J
R523, 524	CARBON FILM RESISTOR	RD1/4PMF470J
R525, 526	CARBON FILM RESISTOR	RD1/4PM221J
R527-530	METAL OXIDE RESISTOR	RS2LMFR68J
R531, 532	CARBON FILM RESISTOR	RD1/4PMF100J
R535, 536	CARBON FILM RESISTOR	RD1/4PMFL100J
R573, 574	METAL OXIDE RESISTOR	RS2LMF010J
R601, 602	CARBON FILM RESISTOR	RD1/4PM100J
R603	METAL OXIDE RESISTOR	RS2LMF102J
R616	METAL OXIDE RESISTOR	RS2LMFR22J
R621	METAL OXIDE RESISTOR	RS2LMF101J
R624	METAL OXIDE RESISTOR	RS2LMF821J
R625	METAL OXIDE RESISTOR	RS2LMF221J
R626	METAL OXIDE RESISTOR	RS2LMF181J
R627	CARBON FILM RESISTOR	RD1/4PM682J
R633	METAL OXIDE RESISTOR	RS2LMF221J
R634	METAL OXIDE RESISTOR	RS2LMF681J
R637	CARBON FILM RESISTOR	RD1/4PM3R9J
R638	METAL OXIDE RESISTOR	RS2LMF101J
R639, 640	CARBON FILM RESISTOR	RD1/4PM100J
	Other resistors	RD1/8PM□□□J


Mark No.	Description	Parts No.
OTHERS		
CN	SPEAKER TERMINAL 2-P	AKE1031
CN107	CONNECTOR (10P)	KPE10
CN108	CONNECTOR (11P)	KPE11
CN111	CONNECTOR (15P)	KPE15
	PIN JACK 2P (SURROUND)	AKB1100
	PIN JACK 4P (CD, PHONO)	AKB1124
	JACK (TURNTABLE)	AKN-203
	JACK (CONTROL)	AKN-207

The other assemblies of RX-Z45/HEXJ is the same as that of RX-Z35/SDXJ, refer to " 3. PCB PARTS LIST ".

6.3 SCHEMATIC DIAGRAMS AND PCB PATTERNS

6.3.1 Overall Schematic Diagram





1. RESISTORS:

Indicated in Ω , $\frac{1}{4}W$, $\frac{1}{8}W$, $\pm 5\%$ tolerance unless otherwise noted k : k Ω , M : M Ω , (F) : $\pm 1\%$, (G) : $\pm 2\%$, (K) : $\pm 10\%$ (M) : $\pm 20\%$ tolerance

2. CAPACITORS:

Indicated in capacity (μF)/voltage (V) unless otherwise noted p : pF
Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE, CURRENT:

V : Signal voltage at rated output.

⏏ : DC voltage (V) at no input signal

Value in () is DC voltage at rated power.

← mA : DC current at no input signal

mV : Signal voltage at FM 1kHz ± 75 kHz DEV.

4. OTHERS:

➔ : Signal route.

⊗ : Adjusting point.

The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

* marked capacitors and resistors have parts numbers.

This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.

5. SWITCHES (The underline indicates the switch position)

POWER assembly

S201 CHANNEL STEP (9k/10k)

SWITCH assembly

S2061 HIGH-SPEED COPY

S2062 DOLBY NR ON/OFF

DISPLAY assembly

S51 TAPE
S53 ST. CALL
S54 SURROUND & STEREO WIDE
S55 TUNING (UP)
S56 POWER/STANDBY
S57 MEMORY
S58 TUNER
S59 PHONO
S60 TUNING (DOWN)
S61 CD
S62 BAND
S64 FM MONO


Line Voltage Selection

Line voltage can be changed with the following steps.



1. Disconnect the AC power cord.
2. Remove the top cover.
3. Change the connection with the power transformer (T1) primary taps.
4. Stick the line voltage label on the rear panel.

Part No.	Description
AAX-193	220V label
AAX-192	240V label

This P. C. B. connection diagram is viewed from the foil side.




To TRANS assembly



POWER assembly (AW3396a)


A

CASSETTE MECHA UNIT (1/3)(AWY1174)




B

CASSETTE MECHA UNIT (2/3)(AWY1174)





C

CASSETTE MECHA UNIT (3/3)(AWY1174)






D






1. This P.C.B connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.


P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
		Transistor
		Radiator type transistor
		Diode
		Resistor
		Capacitor (Polarized)
		Capacitor (Non-polarized)


P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with $\odot$ (double circles) shows negative terminal.
4. The diode terminal marked with $\odot$ (double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.



Assembly J111 (➡ P92)






A


B

C

D



This P. C. B connection diagram is viewed from the parts mounted side.



NOTE

1. This P.C.B. connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the following Table.

P.C.B. pattern diagram indication	Corresponding part symbol	Part Name
Q504		Transistor
Q215		Radiator type transistor
D203		Diode
R237		Resistor
C513		Capacitor (Polarized)
C518		Capacitor (Non-polarized)

Others

P.C.B. pattern diagram indication	Part Name
IC	IC
S	Switch
RY	Relay
L	Coil
F	Filter
VR	Variable resistor or Semi-fixed resistor

3. The capacitor terminal marked with ⊕ (double circles) shows negative terminal.
4. The diode terminal marked with ⊕ (double circles) shows cathode side.
5. The transistor terminal to which E is affixed shows the emitter.


A



C

D

P. C. B. connection diagram is viewed from the foil side.



-To HEADPHONE assembly

A



B

C


D

This P. C. B. connection diagram is viewed from the foil side.





6.3.5 POWER SUPPLY SECTION (RX – Z35/YPWXJ)



1. RESISTORS:
Indicated in Ω , $\frac{1}{4}W$, $\frac{1}{8}W$, $\pm 5\%$ tolerance unless otherwise noted k : k Ω , M : M Ω , (F) : $\pm 1\%$, (G) : $\pm 2\%$, (K) : $\pm 10\%$ (M); $\pm 20\%$ tolerance
2. CAPACITORS:
Indicated in capacity (μF)/voltage (V) unless otherwise noted p : pF
Indication without voltage is 50V except electrolytic capacitor.
3. VOLTAGE, CURRENT:
[V] : Signal voltage at rated output.
[V] : DC voltage (V) at no input signal
Value in () is DC voltage at rated power.
mA : DC current at no input signal
mV : Signal voltage at FM 1kHz ± 75 kHz DEV.

4. OTHERS:
→ : Signal route.
⊗ : Adjusting point.
The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
※ marked capacitors and resistors have parts numbers.
This is the basic schematic diagram, but the actual circuit may vary due to improvements in design.


5. SWITCHES (The underline indicates the switch position)

POWER assembly
S201 CHANNEL STEP (9k/10k)

SWITCH assembly
S2061 HIGH-SPEED COPY
S2062 DOLBY NR ON/OFF

DISPLAY assembly
S51 TAPE
S53 ST. CALL
S54 SURROUND & STEREO WIDE
S55 TUNING (UP)
S56 POWER/STANDBY
S57 MEMORY
S58 TUNER
S59 PHONO
S60 TUNING (DOWN)
S61 CD
S62 BAND
S64 FM MONO
S65 VOCAL CANCEL
S2063 SUPER BASS

7. PANEL FACILITIES



REAR PANEL FACILITIES

Cassette deck receiver: RX-Z15/RX-Z35/RX-Z45

① FM/AM ANTENNA terminals
Antennas must be connected to these terminals: otherwise you will not be able to receive stations.

② Ground terminal (GND)
Connect this to the ground terminal on the turntable (except for PL-Z85).

③ PHONO input jacks
Connect the audio cord of the turntable to these jacks.

④ CD input jacks
Connect to output jacks of a CD player.

⑤ TURNTABLE (DC 12 V OUTPUT) jack
This jack supplies power to the turntable PL-Z85.
Connect the power supply cord of the turntable to this jack.

For U.S. model:
In the U.S.A., model PL-Z85 is not sold, so do not use this jack.
If you are using a turntable, be sure that it is a PIONEER model.

⑥ CONTROL OUT jack
Connect to a compact disc player PD-Z65, PD-Z75T, PD-Z74T or PD-Z85M CONTROL jack.

For U.S. model:
In the U.S.A., only the PD-Z85M can be connected.

⑦ SPEAKERS jacks
Connect exclusive S-Z35D speakers to these jacks.
L: Connect the left speaker system as seen from the listening position.
R: Connect the right speaker system as seen from the listening position.

⑧ SURROUND SPEAKERS jacks
Connect the surround speaker systems.
NOTE:
Connect a speaker system having a nominal impedance of 16 Ω or more.






⑨ AC OUTLET (SWITCHED 50 W MAX)
Power supplied through this outlet is turned on and off by the cassette deck receiver's POWER switch. Total electrical power consumption of connected equipment should not exceed 50 W.

[U.S. and Canadian models]
AC OUTLET (SWITCHED 50 W (0.4 A) MAX)
Power supplied through this outlet is turned on and off by the cassette deck receiver's POWER switch. Total electrical power consumption of connected equipment should not exceed 50 W (0.4 A).

NOTE:
Do not connect appliances with high power consumption such as heaters, irons, or television sets to the AC OUTLET in order to avoid overheating or fire hazard.
This can cause the cassette deck receiver to malfunction.

⑩ Power cord
Connect this to the household electrical outlet.

RX-Z35



FRONT PANEL FACILITIES

Cassette deck receiver RX-Z15/RX-Z35/RX-Z45

- Illustration shows model RX-Z35.

[Tuner Section]

① Remote sensor window (REMOTE SENSOR)

② FM MONO button

Turn on when there is much noise during reception of FM stereo broadcasts. The reproduced sound will become monaural but noise will be reduced.

③ Display section

Shows received broadcast frequency or station call no.
FM and MHz light: FM reception.
AM and kHz light: AM reception.
Ch display: station call no. display

④ FM MONO indicator

Lights when the FM MONO button is set to ON. When this indicator is lit, FM stereo broadcasts are reproduced monaurally.

⑤ STEREO indicator

Lights when an FM stereo broadcast is received (FM MONO button set to OFF).

⑥ TUNED indicator

Lights when a broadcast is received and tuned in well.

⑦ MEMORY button

Used for memorizing stations

⑧ ST. (Station) CALL button

Use to switch between frequency display and station no. display.
During frequency display, you can use the + and - buttons ⑩ to raise or lower the received frequency.
During station no. display, you can use the + and - buttons ⑩ to raise or lower the received station number.

⑨ BAND selector button

Each time this button is pressed, FM or AM reception is selected alternately.

⑩ +, - (UP, DOWN) buttons

Used for locating stations.
Use "—" button for lower, and "+" button for higher station no. or frequencies.

[Amplifier and Graphic Equalizer Section]

① Graphic equalizer controls

② Spectrum analyzer display (RX-Z35, RX-Z45) Level indicator (RX-Z15)

③ SURROUND & STEREO WIDE button/indicator

By turning this switch ON, you can enjoy surround reproduction when rear speakers are used.

By turning this switch ON, you can enjoy STEREO WIDE reproduction with greater left-right spread when rear speakers are not used.
The indicator lights when SURROUND & STEREO WIDE is on.

NOTE:

In the case of monaural source, SURROUND & STEREO WIDE effects cannot be obtained.

④ VOLUME control

⑤ POWER STANDBY/ON switch /STANDBY indicator

This is the switch for electric power.

ON : When set to the ON position, power is supplied and the unit becomes operational.

STANDBY : When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness.

The unit is in STANDBY when only the STANDBY indicator above the POWER switch is lit.

Press the SLEEP button on the remote control to operate the sleep timer, and the STANDBY indicator flashes to show that the sleep timer is operating.

⑥ VOCAL CANCEL button/indicator (RX-Z15, RX-Z35)

When set to ON, the sound volume of vocal sound is lowered.

⑦ SUPER BASS button/indicator (RX-Z35 only)

Set to ON to augment bass frequency response.

⑧ INPUT SELECTOR buttons

[TUNER]

Press to listen to radio broadcast.

[TAPE]

Press to listen to cassette tape.

[CD]

Press to listen to a CD player connected to the CD jacks.

[PHONO]

Press to play records on a turntable connected to the PHONO jacks.

⑨ ECHO control (RX-Z35 only)

Use to control the echo level of the microphone connected to the MIC jack.

⑩ MIC LEVEL control (RX-Z15, RX-Z35)

Used for adjusting the volume of the microphone.

⑪ MIC (Microphone) jack (RX-Z15, RX-Z35)

This is a standard jack for connecting a microphone.

[Cassette Deck Section]

- Use TYPE I (normal) tape.
- Tapes can be played back on Deck I; tapes can be played back and recorded on Deck II.

① Deck I cassette door

② Deck II cassette door

③ HI-SPEED COPY button/indicator (RX-Z35, RX-Z45, and RX-Z15 U.S. and Canadian models)

Used for high-speed tape copying. Copying at about twice normal tape speed.

④ DOLBY* NR switch (RX-Z35, RX-Z45, and RX-Z15 U.S. and Canadian models)

Set this switch to the ON position to activate the DOLBY NR system.

- Tapes recorded using Dolby noise reduction should always be played back with the noise reduction system on. Sound quality will be adversely affected if played back with the system off, or if tapes recorded using a different noise reduction system are played back with the Dolby NR system on.
- It is recommended that tapes recorded with Dolby B type NR be so marked on the label. This will help prevent incorrect setting of the noise reduction switch during playback.

*

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.

"DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

⑤ PHONES (Headphones) jack

For stereo headphones.

NOTE:

There is no output from the speakers when headphones are plugged into PHONES jack.

⑥ Deck I operation buttons

- ▶ (PLAY)..... For playing back a tape.
- ▶▶ (F.F.)..... Fast forward.
- ◀◀ (REW)..... Rewind.
- /▲ (STOP/EJECT) Press to stop playback. Pressing when the deck has stopped playing opens the cassette door.
- || (PAUSE)..... Temporarily stops tape travel. Cancels pause mode when pressed again.

⑦ Deck II operation buttons

- (REC) Press this button, and the ▶ button is simultaneously pressed for you to start recording.
- ▶ (PLAY)..... For playing back a tape
- ▶▶ (F.F.)..... Fast forward
- ◀◀ (REW)..... Rewind
- /▲ (STOP/EJECT) Press to stop recording or playback, and to eject the cassette tape.
- || (PAUSE) Press to pause during playback or recording. To cancel the pause mode, press again.

Remote control unit

① POWER button

② FUNCTION button

Each time you press this button, the input selector changes.

③ SURR. & ST WIDE button

Turns SURROUND & STEREO WIDE on and off.

④ CD operation buttons

Perform the connections so that the CD player is operated by the remote control unit.

- ▶ Play
- ◀◀, ▶▶... Track search
- Stop
- || Pause
- DISC..... Use to select discs on the twin-tray CD player (PD-Z75T) and the Multi-play CD player (PD-Z85M).
- RANDOM ... Press when you want to enjoy random play on the CD player.

⑤ VOLUME + (UP) and – (DOWN) buttons

When pressed, VOLUME on the receiver is actually moved by a motor.

⑥ TUNER STATION + and – buttons

- Before operation, memorize broadcast stations.
- + ... Stations change in order in the upward direction
- ... Stations change in order in the downward direction.

⑦ S.BASS button (RX-Z35 only)

Switches S.BASS (SUPER BASS) ON and OFF.

⑧ SLEEP button


Sets the sleep timer. Press this button to set the 60 minute sleep timer.

The receiver input selector automatically switches to the music source being operated when you press the CD playback (▶), cassette deck playback (▶), or tuner station controls.

NOTE:

It is not possible to operate the CD player with the remote control unless the control cord is connected.

Range of remote control



When the remote control unit is pointed at the remote sensor window on the tuner section and any of its buttons is pressed, the tuner and other components can be operated by remote control. Distance: Within a range of approx. 7 meters (23 feet) from the remote sensor window.

Angle: Within approx. 30 degrees from the center of the remote sensor window.

Remote control will not be possible if there is an obstacle between the remote control unit itself and the remote sensor window.

Performance of the remote control unit is adversely affected in the presence of strong fluorescent light. Keep such lights away, especially from the sensor window.

8. SPECIFICATIONS

Cassette deck receiver: RX-Z15/RX-Z35/RX-Z45

Amplifier Section

[RX-Z15 U.S. and Canadian models]

Continuously Average Power Output is 16 Watts* per channel, min., at 8 ohms from 60 Hertz to 20,000 Hertz, with no more than 0.9 % total harmonic distortion.**

** Measured pursuant to the Federal Trade Commission's Trade Regulation rules on Power Output Claims for Amplifiers.*

[RX-Z15 Australian and Multi-voltage models]

Peak Music Power Output 255 W/6 Ω

[RX-Z35 Australian and Multi-voltage models]

Peak Music Power Output 330 W/6 Ω

[RX-Z45]

Continuous Power Output (DIN) 20 W + 20 W
(1 kHz, T.H.D. 1 %, 6 Ω)

Continuous Power Output (RMS) 30 W + 30 W
(1 kHz, T.H.D. 10 %, 6 Ω)

Graphic equalizer frequency band 100 Hz, 330 Hz,
1 kHz, 3.3 kHz, 10 kHz, ± 7 dB

Cassette Deck Section

Systems 4 track, 2-channel stereo

Heads Recording/playback head x 1
Playback head x 1
Erasing head x 1

Motor DC servo 2 speed motor x 1

Wow and Flutter No more than 0.3 % (WRMS)

Fast Winding Time Approximately 105 seconds
(C-60 tape)

Frequency Response (– 20 dB recording):

TYPE I (Normal) 35 Hz to 14,000 Hz ± 6 dB

Signal-to-Noise ratio

Dolby NR OFF More than 50 dB

Noise Reduction Effect (only models featuring built-in Dolby NR)

Dolby B type NR ON More than 10 dB (at 5 kHz)

FM Tuner Section

Frequency range 87.5 MHz to 108 MHz

Usable Sensitivity Mono: 14.2 dBf, IHF (1.4 μ V/75 Ω)

Signal-to-Noise Ratio (IHF, 85 dBf Input) Mono: 70 dB

Antenna Input 75 Ω unbalanced
300 Ω balanced

AM Tuner Section

Frequency Range

With 10 kHz step 530 kHz to 1,700 kHz

With 9 kHz step 531 kHz to 1,602 kHz

Sensitivity (IHF, Loop antenna) 385 μ V/m

Antenna Loop Antenna

Furnished Parts

Operating Instructions 1

Remote Control Unit 1

Dry Cell Batteries 2

FM Antenna 1

AM Loop Antenna 1

Miscellaneous

Power requirements

U.S. and Canadian models AC 120 V, 60 Hz

European model a.c. 230 Volts ~, 50/60 Hz

Australian models a.c. 240 Volts ~, 50/60 Hz

Other destination models

..... AC 110/120–127/220/240 V (Switchable) 50/60 Hz

Power Consumption

RX-Z35/RX-Z45 200 W

RX-Z15

U.S. and Canadian models 80 W

Other destination models 175 W

Dimensions 360 (W) x 272 (H) x 327 (D) mm

14-3/16 (W) x 10-11/16 (H) x 12-7/8 (D) in

Weight (without package) 7 kg (15 lb 7 oz)

• *Specifications and design subject to possible modification without notice due to improvement.*

** *Measured By Audio Spectrum Analyzer.*

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.

"DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.